

# Service Manual

## TABLE OF CONTENTS

|  | PAGE |
|--|------|
| INTRODUCTION .....   | 1    |
| HANDLING THE REMOTE CONTROLLER .....   | 2    |
| FUNCTION BUTTONS .....   | 3    |
| ACCESSING THE SERVICE FUNCTIONS .....  | 4    |
| REMOTE CONTROLLER SERVICE FUNCTIONS .....                                      | 5    |
| Auto-Start Function (F1) .....   | 5    |
| Heating Temperature Compensation (F2) .....                                    | 5    |
| Anti-Cold Air Function (F3) .....  | 5    |
| Indoor Fan Motor Speed Control after Set Temperature is Reached (F4) .....     | 6    |
| Louver Angle Memory Function (F5). ....  | 6    |
| Heating Only or Cooling and Heating Setting (F6). ....                         | 7    |
| Cooling Temperature Compensation (F7). ....                                    | 7    |
| Refrigerant Leakage Detection (F8). ....                                       | 7    |
| Cleaning Filter Reminder (F9). ....  | 7    |
| Filter Replacement Reminder (E1). ....   | 7    |
| Lowest Temperature Setting (E2). ....  | 8    |
| Highest Temperature Setting (E3). ....   | 8    |
| Special Anti-Cold Air Function Setting (E4). ....                              | 8    |
| Priority Setting of Heating or Cooling (only on Multi-Zone Systems) (E5). .... | 8    |
| Network Address Setting (E6). ....   | 8    |
| Capacity Code Selection (E7). ....   | 8    |
| Twins Setting (E8). ....   | 8    |
| Static Pressure Setting (E9). ....   | 8    |
| DEFAULT VALUES OF INDOOR UNITS .....   | 9    |
| POINT CHECK FUNCTION .....   | 9    |

## INTRODUCTION

This service manual provides the necessary information to use the service functions on the RG57 wireless remote controller. Use the Table of Contents to locate a desired topic.



**Fig. 1 – Remote Controller**

# HANDLING THE REMOTE CONTROLLER

## Remote Controller Location

Keep the remote controller within a distance where its signals can reach the indoor unit's receiver (not to exceed a distance of 26 ft. (8m)).




Fig. 2 – Remote Controller Location



## CAUTION

- The air conditioner will not operate if curtains, doors or other materials block the signals from the remote controller to the indoor unit.
- Prevent any liquid from falling on or into the remote controller. Do not expose the remote controller to direct sunlight or heat.
- If the infrared signal receiver on the indoor unit is exposed to direct sunlight, the air conditioner may not function as designed. Use curtains to prevent sunlight from shining directly on the air conditioner.
- If other electrical appliances respond to the remote controller, either move the appliances or consult your local dealer.

## Replacing Batteries

The remote controller uses two alkaline dry batteries (AAA).

- Slide the battery compartment cover off, according to the arrow direction, then replace the old batteries with new batteries.
- Insert the new batteries. Ensure the batteries are installed correctly, based on their (+) and (-) polarities.
- Slide the battery compartment cover back into position.

### NOTE:

- Do not mix old and new batteries or batteries of different types.
- Do not leave the batteries in the remote controller if the remote is not going to be used for 2 or 3 months.
- Dispose old batteries in the appropriate recycle bins.




Fig. 3 – Replacing batteries


## Remote Controller Specification

Table 1—Remote Controller Specification

| Model                  | RG57F3(B)/BGFEU1           |
|------------------------|----------------------------|
| Rated Voltage          | 3.0V (Dry batteries AAA)   |
| Signal Receiving Range | 26 ft. (8m)                |
| Environment            | 23°F (-5°C) ~ 140°F (60°C) |

## FUNCTION BUTTONS

Before you use your new system, familiarize yourself with the remote controller. The following is a brief introduction of the remote controller.



**Fig. 4 – Remote Controller**

**NOTE:** Remote Controller also available through RCD P/N 17317000A34063. Remote Holder P/N 12117000000318.

## ACCESSING THE SERVICE FUNCTIONS

**Caution:** Read and understand the function changes you wish to make in advance. The remote will not read the parameters in the unit.

1. Before using the service functions of the remote, turn OFF the indoor unit with the remote.
2. Turn off the power to the outdoor unit for 2 minutes. Turn the power back on.
3. Remove the batteries from the remote and wait for the remote screen to clear.
4. Within 30 seconds of replacing the batteries, simultaneously press **MODE** and **TIMER ON** for five (5) seconds.
5. You are now in the **SERVICE FUNCTION** mode – and the remote display reads **F1**.
6. Use **TEMP UP/DOWN** to find and display the parameter you want to change.
7. When the parameter you want to change is displayed, press **MODE** (parameters displayed after pressing **MODE** are default values only, NOT the values stored in the controller).
8. To change the parameter use the **TEMP UP/DOWN** until the value you want is displayed.
9. Press **TIMER ON** to confirm the new setting value and transmit it to the Indoor Unit. “LL” will briefly be displayed on the indoor unit.
10. Repeat steps 6 thru 9 for any other parameter you are changing
11. When finished with ALL changes, simultaneously press **SLEEP** and **DIRECT** for two (2) seconds until display beeps.
12. Remove batteries from the remote and wait for one (1) minute before replacing them. Wait another thirty (30) seconds after remote display returns to set point value.
13. The remote is now restored to normal function and you may operate the system – you do NOT have to cycle power again.




Fig. 5 – Remote Controller

**IMPORTANT:** The remote controller is enabled within 10 minutes after the indoor unit is powered on, and the indoor unit must be turned off.




**POWER OFF:** Press to turn off the unit

Fig. 6 – Power Off



**MODE:** Use to modify the selected function. Press **MODE** to enter the parameter setting interface, and the selected parameter indicator will flash. Use **TEMP ▲ and ▼** to modify the parameter or select another parameter in conjunction with **FAN** and **TIMER OFF**.

Fig. 7 – Mode




**TEMP ▲ and ▼:** Use to select fuctions or adjust parameters. On the parameter unadjustable interface, press **▲ and ▼** to select the specified function in a range of F1~F9 and E1~E9. Next, press **MODE** to enter the parameter modifying interface and the relevant parameter flashes. Press **▲ and ▼** to adjust the parameter.

Fig. 8 – Temp



**TIMER ON:** Press to confirm the setting parameter and transmit the signal to the unit.

Fig. 9 – Timer ON



**FAN & TIMER:** On the parameter setting interface, press **FAN** and **TIMER OFF** to select the parameter to modify.

Fig. 10 – Fan and Timer



**LOCK:** Press and hold **SLEEP** and **DIRECT** for 2 seconds, all the indoor unit's current settings are locked in and the remote controller will not accept any operation other than the **LOCK** operation.

Fig. 11 – Lock

# REMOTE CONTROLLER SERVICE FUNCTIONS

**NOTE:** The indoor unit beeps for 2 seconds indicating the function has been successfully set.

## Auto-Start Function (F1)

In case of a sudden power failure, the module memorizes the setting conditions before the power failure. The unit resumes the previous operation setting automatically after 3 minutes when the power returns. In order to enable/disable this function:

1. Press **▲** and **▼** to select “F1”.




Fig. 12 – Select F1

2. Press **MODE**. Next, press **▲** and **▼** to select “ON” or “OFF”.




Fig. 13 – Select On or Off

3. Press **TIMER ON** and the Auto-start function setting is complete.



Fig. 14 – TIMER ON

## Heating Temperature Compensation (F2)

Defines the adjustment for the thermal stratification in the room and how the indoor unit is sensing the space. To adjust the temperature compensation, in Celsius only:

**NOTE:** The temperature compensation in Celsius regardless of the units used.

1. Press **▲** and **▼** to select “F2”.




Fig. 15 – Select F2

2. Press **MODE**. Next, press **▲** and **▼** to select the parameter (range:  $-6^{\circ}\text{C} \sim 6^{\circ}\text{C}$ ).




Fig. 16 – Select the parameter

3. Press **TIMER ON** to confirm.



Fig. 17 – Timer On

**NOTE:** The recommended setting is  $0^{\circ}\text{C}$ . The adjustment should not be more than  $2^{\circ}\text{C}$ .

## Anti-Cold Air Function (F3)

### A) Intelligent Anti-Cold Air Function

**NOTE:** The intelligent anti-cold air parameter changes with the room temperature. Once the room temperature rises, the anti-cold air temperature rises as well, which is designed to provide the user with increased comfort. After the room temperature decreases, the anti-cold temperature decreases as well, which is designed to improve fan speed and result in a faster heating operation.

**NOTE:** No setting adjustment recommended.

1. Press **▲** and **▼** to select “F3”.




Fig. 18 – Select F3

2. Press **MODE**. Press **FAN** to select the parameter. Next, press **▲** and **▼** to select 1.




Fig. 19 – Select 1

3. Press **TIMER OFF** to adjust the parameter. The parameter continues to flash. Next, press **▲** and **▼** to adjust the parameter (range:  $63^{\circ}\text{F}$  ( $17^{\circ}\text{C}$ )  $\sim 70^{\circ}\text{F}$  ( $21^{\circ}\text{C}$ )).




Fig. 20 – TIMER OFF

4. Press **TIMER ON** to confirm.




Fig. 21 – Timer On

## B) General Anti-Cold Air Function Setting (Cold Blow Prevention Function)

The general anti-cold air parameter is set regardless of the room temperature.


**NOTE:** No setting adjustment recommended.

1. Press **▲** and **▼** to select “F3”.




**Fig. 22 – Select F3**

2. Press **MODE**. Press **FAN** to select the parameter. Next, press **▲** and **▼** to select “2”.



**Fig. 23 – Select 2**

3. Press **TIMER OFF** to adjust the parameter, which continues to flash. Next, press **▲** and **▼** to adjust the parameter (range: 46°F(8°C) ~ 82°F(28°C)).



**Fig. 24 – Adjust the parameter**


4. Press **TIMER ON** to confirm.



**Fig. 25 – TIMER ON**


## Indoor Fan Motor Speed Control after Set Temperature is Reached (F4)

1. Press **▲** and **▼** to select “F4”.



**Fig. 26 – Select F4**

2. Press **MODE**. Next, press **▲** and **▼** to select “1”, “2”, “3”, or “4”.



- [Box 1] Indicates fan motor stopping
- [Box 2] Indicates unit operating at lowest fan speed
- [Box 3] Indicates unit operating at setting fan speed
- [Box 4] Indicates intermittent function (1 min ON / 4 min OFF)

**Fig. 27 – Select a number**


3. Press **TIMER ON** to confirm.



**Fig. 28 – TIMER ON**


## Louver Angle Memory Function (F5)

1. Press **▲** and **▼** to select “F5”.



**Fig. 29 – Select F5**

2. Press **MODE**. Next, press **▲** and **▼** to select “1”, “2”, or “3”.



- [Box 1] Indicates memory function cancellation
- [Box 2] Indicates the louver angle memory function is enabled either by turning off or a power failure
- [Box 3] Indicates the louver angle memory function is enabled by turning off and disabled due to a power failure

**Fig. 30 – Select a number**

3. Press **TIMER ON** to confirm.



**Fig. 31 – TIMER ON**

## Heating Only or Cooling and Heating Setting (F6)

1. Press **▲** and **▼** to select “F6”.




Fig. 32 – Select F6

2. Press **MODE**. Next, press **▲** and **▼** to select “HH” or “CH” (HH: Heating only – CH: Cooling and Heating).




Fig. 33 – Select HH or CH

3. Press **TIMER ON** to confirm.



Fig. 34 – TIMER ON

## Cooling Temperature Compensation (F7)

Defines the adjustment for the thermal stratification in the room and how the indoor unit is sensing the space. To adjust the temperature compensation, in Celsius only:

**NOTE:** Temperature compensation in Celsius regardless of the units used.

1. Press **▲** and **▼** to select “F7”.




Fig. 35 – Select F7

2. Press **MODE**. Next, press **▲** and **▼** to select the parameter (range: -2°C ~ +2°C).

3. Press **TIMER ON** to confirm.



Fig. 36 – TIMER ON

## Refrigerant Leakage Detection (F8)

1. Press **▲** and **▼** to select “F8”.




Fig. 37 – Select F8

2. Press **MODE**. Next, press **▲** and **▼** to select “ON” or “OFF”.

3. Press **TIMER ON** to confirm.



Fig. 38 – TIMER ON

## Cleaning Filter Reminder (F9)

1. Press **▲** and **▼** to select “F9”.




Fig. 39 – Select F9

2. Press **MODE**. Next, press **▲** and **▼** to select “ON” or “OFF”.

3. Press **TIMER ON** to confirm.



Fig. 40 – TIMER ON

## Filter Replacement Reminder (E1)

1. Press **▲** and **▼** to select “E1”.




Fig. 41 – Select E1

2. Press **MODE**. Next, press **▲** and **▼** to select “ON” or “OFF”.

3. Press **TIMER ON** to confirm.



Fig. 42 – TIMER ON

## Lowest Temperature Setting (E2)

1. Press **▲** and **▼** to select “E2”.




Fig. 43 – Select E2

2. Press **MODE**. Next, press **▲** and **▼** to set the temperature (range: 63°F(17°C) to 75°F(24°C)).
3. Press **TIMER ON** to confirm.



Fig. 44 – TIMER ON

## Highest Temperature Setting (E3)

1. Press **▲** and **▼** to select “E3”.




Fig. 45 – Select E3

2. Press **MODE**. Next, press **▲** and **▼** to set the temperature (range: 77°F(25°C) to 86°F(30°C)).
3. Press **TIMER ON** to confirm.



Fig. 46 – TIMER ON

## Special Function Setting (E4)


Not available, used on future applications.

## Priority Setting of Heating or Cooling (only on Multi-Zone Systems (E5))

### CAUTION

All heads must be set to the same priority

1. Press **▲** and **▼** to select “E5”.



**H** : Heating mode first  
**C** : cooling mode first

Fig. 47 – Select E5

2. Press **MODE**. Next, press **▲** and **▼** to select “H” or “C”.
3. Press **TIMER ON** to confirm.



Fig. 48 – TIMER ON

## Network Address Setting (E6)

Not available, used on future applications.

## Capacity Code Selection (E7)

Not available, used on future applications.

## Twins Setting (E8)

Not available, used on future applications.

## Static Pressure Setting (E9)

Available only on 40MBDQ Ducted Units.

1. Press **▲** and **▼** to select “E9”.




Fig. 49 – Select E9

2. Press **MODE**. Next, press **▲** and **▼** to select the values between 0 and 4.
3. Press **TIMER ON** to confirm.



Fig. 50 – TIMER ON

**NOTE:** Depending on the model, some of the remote controller's functions may not function.

# DEFAULT VALUES OF INDOOR UNITS

Table 2—Default Values of Indoor Units

| Description  | Remote Code | High Wall    | Cassette  | Ducted    | Floor Console |
|--|-------------|--------------|-----------|-----------|---------------|
| Auto—Start Function  | <b>F1</b>   | ON           | ON        | ON        | ON            |
| Heating Temperature Compensation                                 | <b>F2</b>   | 2C           | 6C        | 6C        | 0C            |
| Anti—Cold Air Function   | <b>F3</b>   | NORMAL       | NORMAL    | NORMAL    | NORMAL        |
| Indoor Fan Motor Speed Control after Set Temperature is Reached  | <b>F4</b>   | LOWEST SPEED | SET SPEED | SET SPEED | SET SPEED     |
| Louver Angle Memory Function                                     | <b>F5</b>   | ON           | N/A       | N/A       | N/A           |
| Heating Only or Cooling and Heating Setting                      | <b>F6</b>   | CH           | CH        | CH        | CH            |
| Cooling Temperature Compensation                                 | <b>F7</b>   | —2C          | —2C       | —2C       | —2C           |
| Refrigerant Leakage Detection                                    | <b>F8</b>   | ON           | ON        | ON        | ON            |
| Cleaning Filter Reminder   | <b>F9</b>   | OFF          | OFF       | OFF       | OFF           |
| Filter Replacement Reminder                                      | <b>E1</b>   | OFF          | OFF       | OFF       | OFF           |
| Lowest Temperature Setting                                       | <b>E2</b>   | 17C          | 17C       | 17C       | 17C           |
| Highest Temperature Setting                                      | <b>E3</b>   | 30C          | 30C       | 30C       | 30C           |
| Special Anti—Cold Air Function Setting                           | <b>E4</b>   | N/A          | N/A       | N/A       | N/A           |
| Priority Setting of Heating or Cooling (Multi—Zone Systems only) | <b>E5</b>   | H            | H         | H         | H             |
| Network Address Setting  | <b>E6</b>   | N/A          | N/A       | N/A       | N/A           |
| Capacity Code Selection  | <b>E7</b>   | N/A          | N/A       | N/A       | N/A           |
| Twins Setting  | <b>E8</b>   | N/A          | N/A       | N/A       | N/A           |
| Static Pressure Setting  | <b>E9</b>   | N/A          | N/A       | 0         | N/A           |

## POINT CHECK FUNCTION

Press **LED** on the remote controller three times and then press **SWING** three times within 10 seconds, the buzzer rings for 2 seconds and the air conditioner enters the information enquiry status.

Next, press **LED** to search the information. Press **SWING** to search the remaining information. When the air conditioner enters the enquiry information status, it displays the code name in 2 seconds (see Table 3).

Table 3—Point Check Function

| Enquiry Information                | Displaying Code | Meaning                            |
|------------------------------------|-----------------|------------------------------------|
| T1                                 | T1              | T1 temp.                           |
| T2                                 | T2              | T2 temp.                           |
| T3                                 | T3              | T3 temp.                           |
| T4                                 | T4              | T4 temp.                           |
| T2B                                | Tb              | T2B temp.                          |
| TP                                 | TP              | TP temp.                           |
| TH                                 | TH              | TH temp.                           |
| Targeted Frequency                 | FT              | Targeted Frequency                 |
| Actual Frequency                   | Fr              | Actual Frequency                   |
| Indoor fan speed                   | IF              | Indoor fan speed                   |
| Outdoor fan speed                  | OF              | Outdoor fan speed                  |
| EXV opening angle                  | LA              | EXV opening angle                  |
| Compressor continuous running time | CT              | Compressor continuous running time |
| Causes of compressor stop          | ST              | Causes of compressor stop          |
| Reserve                            | A0              |                                    |
| Reserve                            | A1              |                                    |
| Reserve                            | b0              |                                    |
| Reserve                            | b1              |                                    |
| Reserve                            | b2              |                                    |
| Reserve                            | b3              |                                    |
| Reserve                            | b4              |                                    |
| Reserve                            | b5              |                                    |
| Reserve                            | b6              |                                    |
| Reserve                            | dL              |                                    |
| Reserve                            | Ac              |                                    |
| Reserve                            | Uo              |                                    |
| Reserve                            | Td              |                                    |

When the air conditioner enters the enquiry information status, it displays the code value in the next 25 seconds after the display name appears (see Table 4).

**Table 4—Code Value**

| Enquiry Information   | Display Value             | Meaning   | Remark  |
|---|---------------------------|---|---|
| T1,T2,T3, T4,T2B,TP, TH,<br>Targeted Frequency, Actual<br>Frequency | -1F,-1E, -1d,-1c, -1b,-1A | -25,-24,-23,-22,-21,-20   | 1. The displaying temperature is the actual value.<br>2. The temperature is Celsius no matter what kind of remote controller is used. |
|   | -19~99                    | -19~99  | 3. T1,T2,T3,T4,T2B display range: 77°F(-25°C)~158°F(70°C), TP display range: -20~130.   |
|   | A0,A1...A9                | 100,101.....109   | 4. Frequency display range: 0~159HZ.  |
|   | b0,b1...b9                | 110,111....119  | 5. If the actual value exceeds the range, it displays the maximum value or minimum value.   |
|   | c0,c1....c9               | 120,121....129  |   |
|   | d0,d1...d9                | 130,131....139  |   |
|   | E0,E1...E9                | 140,141....149  |   |
|   | F0,F1...F9                | 150,151....159  |   |
| Indoor fan speed/Outdoor fan speed                                  | 0                         | OFF   |   |
|   | 1,2,3,4                   | Low speed, Medium speed, High speed, Turbo  | For some big capacity motors  |
|   | 14~FF                     | Actual fan speed = Display value turns to decimal value and then multiply by 10. The unit is RPM. | For some small capacity motors, display value is from 14~FF (hexadecimal), the corresponding fan speed range is from 200~2550RPM.     |
| EXV opening angle   | 0~FF                      | Actual EXV opening value = Display value turns to decimal value and then multiply by 2.           |   |
| Compressor continuous running time                                  | 0~FF                      | 0~255 minutes   | If the actual value exceeds the range, it displays the maximum value or minimum value.  |
| Compressor stop causes  | 0~99                      | For a detailed meaning, please consult with an engineer   | Decimal display   |
| Reserve   | 0~FF                      |   |   |