



INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS

1455 Kleppe Lane • Sparks, NV 89431-6467 • (775) 359-4712 • Fax (775) 359-7424
E-mail: haws@hawasco.com • website: www.hawasco.com

No. 0002080250 (27)

Model H1011.8HO/H1011.8HO2 Water Cooler

NOTE TO INSTALLER: Please leave this information with the Maintenance Department.

Haws electric water coolers are not designed or recommended for outdoor or corrosive environments such as enclosed chlorinated pool areas.

Consideration must be made at the time of installation to adhere to state and/or local codes and environmental/atmospheric conditions such as, but not limited to, dust, corrosion, freezing etc. These conditions will void the warranty.

CAUTION! Prior to making any electrical connections, verify with a voltmeter that power from the service panel is **off**.

LIMITED WARRANTY

HAWS warrants that this specific product is guaranteed against defective material or poor workmanship for a period of **one year from date of shipment**. HAWS liability under this warranty shall be discharged by furnishing without charge F.O.B. HAWS Factory any goods, or part thereof, which shall appear to the Company upon inspection to be of defective material or not of first class workmanship, provided that claim is made in writing to Haws within a reasonable period after receipt of the product. Where claims for defects are made, the defective part or parts shall be delivered to the Company, prepaid, for inspection. HAWS will not be liable for the cost of repairs, alterations or replacements, or for any expense connected therewith made by the owner or his agents, except upon written authority from HAWS, Sparks, Nevada. HAWS will not be liable for any damages caused by defective materials or poor workmanship, except for replacements, as provided above. Buyer agrees that HAWS shall not be liable for general, special, or consequential damages claimed to arise under the contract of sale. The drinking fountain manufactured by HAWS is warranted to function if installation and maintenance instructions provided are adhered to. The units also must be used for the purpose for which they were intended.

**NO OTHER WARRANTIES EXPRESSED OR IMPLIED ARE AUTHORIZED,
PROVIDED OR GIVEN BY HAWS.**

SHOULD YOU EXPERIENCE DIFFICULTY WITH THE INSTALLATION OF THIS MODEL PLEASE CALL:

TECHNICAL SUPPORT: 1-800-766-5612
FOR CUSTOMER SERVICE: 1-888-640-4297

RECOMMENDED TOOLS: Hack saw, pipe joint sealant, screwdriver, level, 12" adjustable wrench, 10" pipe wrench, 3/32" and 5/32" hex key wrench, 9/16", 1/2", 7/16" socket wrench or open-end wrench.

LOCATION OF UNIT: The Model H1011.8HO/H1011.8HO2 Cooler is a wheelchair accessible drinking facility. The height dimensions shown, meet current ADA requirements. When installing this unit, local, state or federal codes should be adhered to. If height other than shown is required, then dimensions must be adjusted accordingly.

SUPPLY LINE: The minimum recommended line size is 1/2"IPS with 30-90 psi (2-6 ATM) flowing pressure. Where sediment or mineral content is a problem, an inlet filter is recommended.

PLUMBING CONNECTIONS: Inlet is 3/8" O.D. tube. Waste outlet is 1-1/4" O.D. tube.

ELECTRICAL CONNECTIONS:

Chiller: 115VAC, 60HZ, 4.7 AMPS. Chiller wired direct to incoming line, by others.

Sensor(s):

H1011.8HO with RKHO.120/120P: 120 x 24 VAC, 60Hz, .68 AMPS.

H1011.8HO with RKHO.240: 240 x 24 VAC, 60Hz, .68 AMPS.

H1011.8HO2 with RKHO.120/120P: 120 x 24 VAC, 60Hz, 1.36 AMPS.

H1011.8HO2 with RKHO.240: 240 x 24 VAC, 60Hz, 1.36 AMPS.

MAINTENANCE: Periodically clean strainers (One is inside push button valve on Model H1011.8HO (refer to 5874 Series Valve Manual for details) & other is on inlet side of chiller).

PARTS LIST		
MODEL PACKAGE	QUANTITY	ITEMS INCLUDED
MTGFR.LG	1	Mounting Frame (Required – Sold Separately)
	3	#10 Sheet Metal Screws
HCR8	1	Chiller
H1011.8HO/H1011.8HO2	1 or 2	Bowl Assembly with sensor (One on H1011.8HO & two on H1011.8HO2)
	1	Bowl Assembly with push button valve (one on model H1011.8HO only)
	1	Package supply tubing with strainer
	1	Panel Bowl Back
	1	Grille
	1	Package of two each-grille attachment clips, clip nuts, #10 sheet metal screws and 6-32 screws
	2	Waste elbow 1-1/4" O.D.
	8	5/16 -18 retainer nuts
	8	5/16 – 18 x 1 hex head screws

INSTALLATION PROCEDURE

GENERAL NOTES:

The Model H1011.8HO/H1011.8HO2 Water Cooler Assembly requires installation of the mounting frame as described in Steps 1 – 2, then mounting the fountain bowl assembly as described in Steps 3 – 6, and finally completing chiller water and electrical connections and starting chiller per Steps 7 – 13. First check that all required parts are received.

Grounding may cause electrical feedback into the electric drinking fountain causing an electrolysis, which creates a metallic taste or an increase in the metal content of the water. This condition can be avoided by using dielectric couplings in the assembly. The waste line, which is supplied by the installer, should also have a dielectric (plastic) coupling to completely isolate the assembly from the building plumbing system.

NOTES:

1. For all plastic push-in type fitting connections, only connect NSF-61 copper or plastic tubing. Stainless steel or glass tubing is not recommended. The following assembly instructions must be followed to ensure a watertight connection:
 - a. Cut tubing square and clean.
 - b. Mark from end of tube the length of insertion (See table below).
 - c. Push tube into the fitting until it bottoms out.
 - d. To remove, depress collet and pull tubing out.

Tube Sizes	O.D. Tolerance	Insertion Depth
1/4"	±.005"	11/16"
3/8"	±.005"	3/4"
1/2"	±.005"	7/8"

STEP 1: Provide wall opening as detailed in installation Drawing. Frame must be positioned such that frame flanges overlap and butt against finished wall surface. Mounting holes are provided for #6 sheet metal screws. After frame is positioned in wall, swing chiller support tray into position (See Installation Drawing), align tray holes with holes in frame and fasten with #10 sheet metal screws. Mounted frame must support 50 pound chiller in addition to fountain weight and user generated forces.

STEP 2: Install waste, supply and electrical lines in locations shown in Installation Drawing. Waste and supply lines may be installed for either rear or side entry. Verify proper waste, supply, electrical and frame locations. Use level to verify horizontal and vertical frame mounting to insure proper bowl drainage.

STEP 3: Installation Drawing shows fountain bowls, back panel and grille locations. Unpack bowls and remove bottom plates using 3/32" hex allen wrench. Install back panel on frame with narrower edge to bottom. Position nut retainers into mounting frame and use two 5/16-18x1 hex head screws partially started in outside holes to support panel. Install bowl/bracket assembly onto panel using eight 5/16-18x1 hex head screws hand tightened. See sheet 2 of Installation Drawing for appropriate bowl mounting pattern to use for this model.


INSTALLATION PROCEDURE...

STEP 4: Remove 1-1/2" IPS outlet elbow from traps (not supplied). Install elbow inside frame onto waste stub-outs. Reassemble trap "U" bends with inlets centered behind fountains.

STEP 5: Remove slip joint nuts from bottom of fountain waste outlet. Assemble nut over 1-1/4" O.D. end of waste elbow as supplied by Haws. Assemble waste elbow onto bowl waste body using seal washer provided and tighten nut hand tight. Measure vertical distance down to trap inlet and cut the vertical (not supplied) elbow to length allowing 1/2" minimum for engagement into trap. Mark and similarly cut to length the horizontal waste elbow. Install elbow and tighten all the slip joint nuts.

STEP 6: See Figure 1 (below) for detail section view of side screw grille attachment. Unpack grille and insert upper lip behind bottom of back panel, align sides and hold up flush to bottom of back panel. Hold grille against wall and mark centers of grille side slots on wall. Masking tape may be used to prevent finished wall damage from mark. Install the "s" clips in mounting frame using #10 sheet metal screws into pre-drilled holes on lower end of each side of frame. Tighten #10 screw while holding "s" clips centered on wall marks. Check grille fit by installing grille and partially tightening #6-23 socket head screws through side of grille. Ensure proper panel and grille alignment, then tighten eight 5/16-18x1 hex head screws.

STEP 7: Unpack and remove chiller from carton. Remove front panel screws and panel. Do not remove insulating putty and foam from copper tubes or Styrofoam insulation from evaporator coil. Remove any inner packing, which may be around compressor. If applicable, remove junction box cover and electrical knock out on lower right side of housing. Install fittings (supplied) on chiller inlet and outlet tubes (see Installation Drawing).



INSTALLATION PROCEDURE ...

STEP 8: Thoroughly flush supply line to remove all foreign matter. Connect 1/2" IPS supply screwdriver-stop (not supplied) to stub-out in wall. Place chiller on chiller support tray against right hand side, fully to rear, with condenser (open panel) side facing to front.; Install supply 3/8" O.D. tubing (not supplied), between screwdriver-stop and chiller inlet. (Cut tubing to proper length and follow general notes for proper connection procedures for push-in type fittings). Tubing insulation is not normally required on inlet side of chiller. Install insulated tube between fountain and solenoid valve outlet. Cut tubes as required and connect to solenoid outlet compression fitting. Open screwdriver-stop **wide open** while checking for leaks at all connections. Also, check waste for leaks.

STEP 9: **Model H1011.8HO (only): 5874 Series Valve** - Adjust bubbler stream height using a small flat-head screwdriver inserted through a hole in the center of the push button for increased flow turn clockwise and for decreased flow turn counterclockwise. If flow problems arise, see troubleshooting guide for additional instructions to correct problem. Bubbler stream may lower during short break-in period. Set initial stream height a little high to minimize or eliminate the need for break-in period readjustment.

Model H1011.8HO/H1011.8HO2: 5867 Valve Pressure Regulator – Adjust bubbler stream height using the black pressure regulator mounted inside bracket that has HO sensor unit, by loosening the locknut and rotating the knob clockwise to increase flow or counterclockwise to reduce flow. Tighten the locknut and check flow height. Repeat these steps until the bubbler flow height is correct.

STEP 10: Verify that electrical power is off and power supply voltage, phase and cycle match specifications printed on chiller label. In accordance with local codes, wire directly to incoming lines at internal chiller junction box. Verify that all inner packing is removed and hand rotate fan blade to verify free rotation. Reattach chiller front panel. Turn power on and verify that chiller cycles after water reaches proper temperature. Finally, check fountain for leaks.

STEP 11: RKHO Series Transformer and Sensor Setup: Refer to the RKHO Series manual for instructions (supplied).

STEP 12: Verify the chiller turns off after water reaches proper temperature. If there are any problems, refer to Sensor/Solenoid Troubleshooting Guide section of the RKHO Series manual.

STEP 13: Install grille and tighten outer side screws. Verify there is chilled water out of bubbler.

MAINTENANCE

STEP 1: Periodically clean the strainer located in the push button valve body on Model H1011.8HO (Refer to 5874 Series Valve Manual for more information) and on chiller.

STEP 2: The condenser fins on chiller should be periodically cleaned with brush, air hose or vacuum cleaner. Care should be taken not to bend or deform the condenser fins.

STEP 3: The chiller temperature control is factory set for 50° F water under normal conditions. For colder water, adjust control clockwise. For warmer water, turn counterclockwise. Remove front chiller panel for access to temperature control. After adjustment allow unit to cycle off before checking outlet water temperature.


5874 Series VALVE TROUBLESHOOTING (Model H1011.8HO Only)	
PROBLEM	REPAIR CHECKLIST
1. Insufficient bubbler flow.	<ul style="list-style-type: none"> 1a. Check that inlet screwdriver stop valve is in wide-open position. b. Verify minimum 30 psi flowing supply pressure. c. Clean strainer. See 5874 Series Valve Manual. d. Adjust valve to increase flow. Use front adjust screw or see 5874 Series Valve Manual.
	<ul style="list-style-type: none"> e. Clean screens (inside nozzle body). Unscrew nozzle insert and very gently activate water supply to pop out qty. 3 screens (be careful not to lose screens). Remove any debris clogging the screen openings and place back into nozzle body. Reassemble nozzle insert.
2. Water too warm or cold.	<ul style="list-style-type: none"> a. Adjust chiller temperature control, clockwise for colder water.

For more information about Haws products, see our website: www.hawesco.com


NOTES:

[1] 5874PBF VALVE (ITEM 5), INCLUDES VRK5874
CARTRIDGE ASSEMBLY (ITEM 16), PBA6 FLANGED
PUSH BUTTON (ITEM 4) AND SPANNER WRENCH (ITEM 1).

[2] ITEMS 4, 5 AND 16 ARE ONLY USED ON MODEL H1011.8HO.




ITEM	DESCRIPTION	PART NO.
1	SPANNER WRENCH	0006983506
2	STRAINER ASSY	6463
3	BUBBLER HEAD W/ INSERT	5705
4	BUTTON, PUSH, FLANGED, ASSY	PBA6
5	BUTTON, PUSH, FLANGED, WITH VALVE	5874PBF
6	ACCESS PLATE	PBM1000
7	SENSOR	VRKH01
8	WIRING HARNESS	VRKH02
9	SOLENOID	VRKH03
10	MOUNTING FRAME	MTGFR.LG
11	CHILLER	HCR8
12	PRESSURE REGULATOR	5867
13	BACK PANEL	0004012000
14	GRILLE	0002626651
15	DRIVER, NOZZLE .25 HEX	0002082253
16	VALVE REPAIR KIT	VRK5874



BUBBLER HEAD 5705
(TUBING CONNECTS TO
INSERT ASSY)

DETAIL A
ROTATED 90° INTO VIEW




**H1011.8HO SHOWN
H1011.8HO2 ON SHEET 2
PARTS BREAKDOWN**

WHEN ORDERING PARTS PLEASE SPECIFY MODEL NUMBER.



Haws®

ECN NO.	REVISED PER ECN: 5577	BY FV	MODEL(S)	PART NUMBER 0002080250
DRAWN RTM	DATE 10/21/98	CHKD DP	H1011.8HO/H1011.8HO2	REVISION 27
APPROVED FV	DATE 11/11/20	SCALE: NA	DRAWING TYPE: PARTS BREAKDOWN	SIZE: A SHEET 1 OF 2







H1011.8HO2 SHOWN
H1011.8HO ON SHEET 1

PARTS BREAKDOWN

WHEN ORDERING PARTS PLEASE SPECIFY MODEL NUMBER.


PART NUMBER 0002080250			
DRAWN FV	REVISED PER ECN: 5577	BY FV	MODEL(S)
APPROVED FV	DATE 07/22/20	CHKD DP	H1011.8HO/H1011.8HO2
SCALE: NA	DRAWING TYPE: PARTS BREAKDOWN		SIZE: A
27			SHEET 2 OF 2



MODEL H1011.8HO SHOWN

MODEL H1011.8HO2 ON SHEET 2

(ROUGH-IN DIMENSIONS APPLY TO BOTH MODELS WITH EXCEPTION NOTED ON SHEET 2)






NOTES:

1. HOLD ROUGH-IN DIMENSIONS $\pm 1/8"$ (3.2mm).
2. WHEN INSTALLING THIS UNIT, LOCAL, STATE, OR FEDERAL CODES SHOULD BE ADHERED TO. FOR INSTALLATION DIMENSIONS (LOCATIONS), WASTE AND SUPPLY REQUIREMENTS OTHER THAN SHOWN, DIMENSIONS MARKED (*) MUST BE ADJUSTED ACCORDINGLY.
3. ALIGN HOLES IN CHILLER SUPPORT TRAY WITH HOLES IN FRAME AND FASTEN WITH #10 SHEETMETAL SCREWS.
4. REFER TO 5874 SERIES OPERATION AND MAINTENANCE MANUAL FOR PUSH BUTTON AND VALVE INSTALLATION/MAINTENANCE INSTRUCTIONS.
5. REFER TO MTGFR.LG INSTALLATION DRAWING FOR ROUGH-IN DIMENSIONS.
6. INSERT 5/15-18 PANEL INSERTS FROM OPPOSITE SIDE AT LOCATIONS SHOWN BY DARKENED HOLES. HOLE COMBINATIONS SHOWN ARE FOR USE WITH LOW FOUNTAIN ON THE RIGHT AND HI FOUNTAIN ON THE LEFT. USE OPPOSITE HOLES FOR HI ON RIGHT AND LOW ON LEFT.
7. HOLE COMBINATION SHOWN BELOW IS FOR USE WITH LOW FOUNTAIN ON THE RIGHT AND HIGH FOUNTAIN ON THE LEFT. USE OPPOSITE HOLES FOR HIGH ON RIGHT AND LOW ON LEFT.
8. TO CHANGE FOUNTAIN MTG. SCREW LOCATIONS: FIRST REMOVE SCREWS AND THEN SQUEEZE CLIPS ON NUT RETAINER TO POP OUT. SNAP INTO NEW POSITIONS AND RE-ASSEMBLE SCREWS.
9. IMPORTANT: A L.H. LOW (OPTIONAL) CONFIGURATION WILL REQUIRE A DIFFERENT BACK PANEL AND THE WASTE AND SUPPLY DIMENSIONS SHOWN (*) MUST BE REVERSED.
10. REFER TO RH0 SERIES OPERATION AND MAINTENANCE INSTRUCTIONS FOR TRANSFORMER AND SENSOR SETUP.


IMPORTANT: MOUNTING FRAME
MUST BE INSTALLED SO THAT
FRAME FLANGE BUTTS AGAINST
FINISHED WALL FACE.

Haws®

ECN NO.	REVISED PER	BY:	MODEL(S)	PART NUMBER
	ECN: 5577	FV	H1011.8HO/H1011.8HO2	0002080250.D
DRAWN:	DATE:	CHK'D.:		
RTM	07/97	DP		
APPROVED:	DATE:			REVISION
FV	11/11/20			27
SCALE:	NA	DRAWING TYPE:	INSTALLATION	SIZE: A
				1 SHEET 1 OF 2



MODEL H1011.8HO2 SHOWN
MODEL H1011.8HO ON SHEET 1
(SEE SHEET 1 FOR APPLICABLE ROUGH-IN DIMENSIONS)



 Haws®				1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWSCO.COM WEBSITE: WWW.HAWSCO.COM
ECN NO. <input type="text"/> REVISED PER <input type="text"/> ECN: 6577 FV				MODEL(S)
DRAWN: <input type="text"/> FV	DATE: <input type="text"/> 07/22/20	BY: <input type="text"/> CHK'D.: <input type="text"/> DP	APPROVED: <input type="text"/> FV	DATE: <input type="text"/> 11/11/20
SCALE: <input type="text"/> NA	DRAWING TYPE: <input type="text"/>	INSTALLATION	SIZE: A	HEET 2 OF 2
27				