

## **Installation, Operation and Maintenance**

### **H SERIES Wallmount Heat Pumps R410A Series**



## H SERIES WALLMOUNT HEAT PUMPS

Your equipment is covered by a LIMITED WARRANTY against defects in material and workmanship.

This is a vertical wallmount unit designed for many different applications in both residential and commercial settings. It is self-contained and arrives completely assembled, factory-charged and wired. The unit is 100% run-tested at the factory to ensure proper operation. Your unit is supplied with high-quality copper tubing and enhanced aluminum-finned coils for high heat transfer efficiency and long life. The unit cabinet is constructed of G-90 galvanized steel. All exterior surfaces are finished with a baked-on polyester coating. This will provide excellent corrosion protection in most applications. However, if the unit is installed in an area with a corrosive atmosphere, such as near an industrial plant or on the seacoast, additional coating should be considered to extend the life of the coils and cabinet.

**! DANGER: BEFORE PERFORMING ANY WORK ON THIS EQUIPMENT, POWER SUPPLY MUST BE TURNED OFF AT THE HOUSEHOLD SERVICE BOX TO AVOID THE POSSIBILITY OF SHOCK, INJURY, DEATH OR DAMAGE TO EQUIPMENT.**

This unit was designed for up to 105°F of ambient temperature for cooling mode; for heating mode, this unit was designed for up to 78 °F of room temperature, and minimum of 15°F ambient temperature.

### INSPECTION AND UNPACKING

A thorough inspection of the shipping container should be made immediately upon receiving your unit. Look for any punctures or openings. If it appears as if damage has occurred, it should be noted on the freight bill before signing. The delivering carrier should be contacted immediately to inspect damage, and no installation work should begin until this inspection is completed.

**! WARNING: FAILURE TO FOLLOW THESE RULES AND INSTRUCTIONS COULD CAUSE A MALFUNCTION OR DESTRUCTION OF THE EQUIPMENT WHICH COULD RESULT IN PROPERTY DAMAGE, SERIOUS BODILY INJURY, OR DEATH.**

### SAFETY RULES

1. Installation and repair **MUST** be done by a qualified person. The equipment should be inspected before use and at least once annually by a professional service person.
2. **AVOID ELECTRICAL SHOCK!** Turn power OFF when servicing. There may be more than one disconnect switch to de-energize unit.
3. Close cover(s) before returning breaker(s) to "ON" position.
4. Please observe good safety practices by wearing personal protective equipment such as gloves and safety glasses to avoid injury.
5. Installation **MUST** conform to local codes. In the absence of local codes, refer to the National Electrical Code (NEC), ANS/NFPA No. 70-1993 and recommendations made by the National Board of Fire Underwriters.

In our continuing effort to improve our product, specifications may change without notice. If there are any questions, please see the contact information on the last page of this manual.

**! WARNING: IMPROPER INSTALLATION MAY DAMAGE EQUIPMENT, CAN CREATE A HAZARD, AND WILL VOID THE WARRANTY.**

### OPERATING INSTRUCTIONS

In all cases, the equipment **MUST** be installed in accordance with the installation instructions described in this manual. Set the thermostat to either HEAT or COOL as desired. Set the desired temperature on your thermostat dial and set the fan switch to "ON" (for continuous air circulation) or to "AUTOMATIC" (for air circulation only when the air conditioning system is operating). If you desire to vary the thermostat temperature setting during the day for energy conservation (for example, while you are at work).

**IMPORTANT:** Wait at least three (3) minutes after turning the heat pump off before trying to restart. If an attempt is made to start the compressor before the refrigerant pressures are equalized, the compressor motor may trip on its overload. An additional waiting period will be required before restarting.

### MAINTENANCE

1. Always install and keep filters clean. Check filters 2 weeks. Clean or replace if necessary. The factory-installed filter is located behind the center front access panel.

#### TO CHANGE SYSTEM FILTER:

- A. Turn the power to the unit off at the unit disconnect. The disconnect is located on the front of the H Series unit behind a small access door.
- B. Remove the front center access door from the unit.
- C. Remove and replace the filters with the type and size indicated in the table below.
- D. Replace the access door and turn on the power to the unit.

**NOTE:** If your system has a filter grille installed in the return air opening, the unit filter should have been discarded during installation.

The filter installed into the return air grille assembly should be replaced with the same size and type provided with the grille.

If your system is equipped with a fresh air intake, the filter for the fresh air assembly is accessed through the front center panel. The filter is a permanent washable type.

UNIT MODEL	QTY.	FILTER SIZE	TYPE
18, 24, 30, 36	1	16 x 25 x 1 (standard)	Disposable
18, 24, 30, 36	1	16 x 25 x 2 (optional)	Disposable
48, 60	1	20 x 30 x 1 (standard)	Disposable
48, 60	1	20 x 30 x 2 (optional)	Disposable

## MAINTENANCE

**! WARNING: SERIOUS INJURY MAY RESULT IF WATER SPRAY IS DIRECTED TOWARD LIVE ELECTRICAL CONNECTIONS OR POWER SOURCES.**


### TO CLEAN FRESH AIR INTAKE FILTER:

- Follow steps A and B at left "TO CHANGE SYSTEM FILTER".
  - Gently pull out the filter from the bottom.
  - Wash the filter with water.
  - Reinstall the filter, by sliding it into the retaining rail.
  - Replace the access door and turn the power on to the unit.
- Keep the outdoor coil clean. Wash it down with a garden hose if necessary. **BE SURE THE UNIT DISCONNECT IS IN THE "OFF" POSITION AND THAT ALL ELECTRICAL POWER TO THE UNIT IS TURNED OFF BEFORE CLEANING THE SYSTEM.**

Remove any loose grass, leaves, papers, etc., from the area around the condenser coil. These could reduce the air supply through the coil and reduce the amount of cooling capacity.

- Since the heat pump is located outdoors, it is exposed to all weather elements. Treat it with a good automobile paste wax twice a year (in the spring and fall).

Check with your contractor if you have any questions regarding the maintenance or operation of your unit.



## INSTALLATION

### A. CODES

The installer SHALL comply with all local, state, and federal codes and/or regulations pertaining to this type of equipment and its installation. Such codes and/or regulations should take precedence over any recommendations contained herein in lieu of local codes. Installations SHALL be made in accordance with the National

### B. UNIT SITE LOCATION

Electrical Code, local codes, and recommendations made by the National Board of Fire Underwriters.

- To eliminate noise from being transmitted into noise-sensitive areas, the unit should **NOT** be installed on walls adjoining bedrooms, sleeping quarters, or adjacent to windows.
- Locating the unit as close as possible to the main duct system or area to be conditioned, will prevent lengthy duct runs and unnecessary thermal and air-pressure losses.
- The clearance to combustibles is 0" on all sides, and 1/4" for the first three (3) feet of supply duct.
- The condenser air inlets (left, right and bottom inlets) SHALL be located at least 12" away from walls or other obstructions for unrestricted airflow.
- The condenser air outlet should be located at least 6' away from any obstructions to prevent recirculation of condenser air.
- Service clearance is 28" from the electrical box access panel

located on the front of the unit and 28" from the center, upper, and lower front access panels.

- The wall selected for unit installation **MUST** be able to or be made to safely support the weight of the unit.
- Do **NOT** locate where heat, lint or exhaust fumes will be discharged on the unit (as from dryer vents).

## C. UNIT PREPARATION

- The H Series model units have top rain flashing built onto the unit. The bottom-mounting flange for all models is shipped separately and in place. (Refer to "Section J. Unit Installation" for the recommended use of the bottom flange.)
- Electrical entrances are located on the right side, left side, and back of all H Series units. Refer to "Section H. Electrical Hook-up" for details.
- Bend the lids of the return and supply openings to form a return and supply air collars and install air gaskets.
- The supply and return air ducts should be checked to be sure they:
  - Match the openings on the unit to be installed.
  - Have the same distance between them vertically as the openings on the unit to be installed.
- If the factory-installed filter is used on your installation, access to the filter is made through the center panel on the front of the unit. **IF A REMOTE FILTER IS USED, SUCH AS A FILTER GRILLE, THE FACTORY-INSTALLED FILTER MUST BE REMOVED AND DISCARDED.**

## D. DUCTWORK

- Properly-sized duct systems are critical for satisfactory operation of any heat pump system. All ductwork **MUST** be correctly sized for the design air flow requirement of the equipment.
- The recommended operation duct static is to deduct 0.07" W.C. for any size of heater 5 kW to 20 kW on factory- or field-installed heaters.
- Ductwork routed through wall cavities, as well as any duct not in conditioned space, **MUST** be insulated. Supply ducting routed through exterior walls **MUST** be insulated with 1" insulation to the back of the unit.
- Supply and return air ducts should be flush with the exterior wall and sized to fit over the unit duct collars in order to compress the collar air gasket.
- If supply duct is flashed to the exterior of a building constructed with combustible material, the flashing **MUST** be insulated in order to maintain the required clearances to combustible materials. Required clearance is 1/4" for the first three (3) feet of supply duct.

## E. FILTERS


- One-inch disposable filters are supplied standard in each unit. Two-inch disposable filters can also be used and are available as an option. The filter rack is adjustable to accommodate 2" filters. The filter rack on this series is adapted by bending the retaining brackets. Refer to the Maintenance section on page 3 for the procedures for changing the filters.
  - If a filter grille is used in the installation, the filter should be properly sized to allow a maximum velocity of 400 FPM. **THE FACTORY-INSTALLED FILTER MUST BE REMOVED.**

## F. ELECTRICAL POWER

The installer MUST check available power to make certain it matches the unit nameplate rating and that constant voltage can be maintained to the unit. Unsatisfactory and unsafe performance could otherwise result. The local power company should be contacted about questions concerning power supply.

## G. BREAKER/DISCONNECT ASSEMBLY

These units are standard equipped from the factory with a unit disconnect. This is in the form of a circuit breaker (230V models) or a disconnect (460V models). If an optional electric heat kit is to be installed, follow the instructions included with the heater assembly. See Figure 1 for reference.



**! WARNING: ELECTRICAL EQUIPMENT SHOULD BE INSTALLED BY A QUALIFIED, LICENSED ELECTRICIAN. IMPROPER ELECTRICAL HOOK-UP MAY DAMAGE EQUIPMENT, CAN CREATE A HAZARD, AND WILL VOID WARRANTY.**

## H. ELECTRICAL HOOK-UP

The line voltage electrical service can be routed through the right side panel, the right side of the back panel, or left side panel. Each area is supplied with two line voltage knock-outs ( $\frac{1}{2}$ " –  $\frac{3}{4}$ " and 1" –  $1\frac{1}{4}$ "). Low voltage wiring can be routed through the right side panel.

**NOTE:** When routing line voltage through the return air compartment, conduit MUST be used (even though this is a dry area) to comply with the NEC code. A  $1\frac{1}{4}$ " PVC conduit is supplied for this application. Refer to the ELECTRICAL tables for minimum wire size and maximum breaker size. All wire sizes listed under the dual-feed circuit column are based on no more than three (3) conductors in the same conduit. If two circuits or more than three (3) conductors are to be routed in the same conduit, the ampacity of the wire size listed MUST be derated. Refer to Article 310 of the NEC code for adjustment factors. Be sure to install a ground wire of the proper size to the unit's equipment ground lug.

## I. LOW VOLTAGE WIRING

230 volt, 1- and 3-phase units are equipped with dual-primary voltage transformers for 208/240 volt operation. These models are factory wired to the 240 volt tap. For 208 volt operation, connect the factory-installed black wires from the 240 volt tap to the 208 volt tap. The acceptable voltage range of the tap is as follows:

Tap	Voltage Range
240 Volt	253 - 216
208 Volt	220 - 187

Seven (7) conductor thermostat wires should be run from the thermostat location to the unit. Thermostat wire should be sized as shown on the table below.

Wire Gauge	Maximum Length
20	45'
18	60'
16	100'
14	160'
12	250'

Refer to wiring diagrams on for connection details.

## STAGING OF ELECTRIC HEAT

All H Series units with electric heat assemblies are wired for two-stage heat in normal operation. Units over 10 kW resistance heat also have an additional stage for emergency heat. The first stage is refrigerant heat (Y and G terminals are energized and O terminal is de-energized). The second stage is auxiliary resistance heat (W is energized). The third stage is emergency heat (E and W terminals are energized). H Series units are equipped with an emergency heat lock-out relay. This will disable the compressor when the E terminal is energized. Do not install a jumper between the W and E terminals. This would keep the compressor contacts from being energized and prevent the compressor from operating.

## J. UNIT INSTALLATION

### H SERIES UNITS ARE FOR USE IN SINGLE-STORY BUILDINGS ONLY


- As previously stated, the wall that the unit is to be installed onto MUST be strong enough to support the unit under the condition for which it will be used. For example, a unit to be installed on a building that is intended to be transported will require more wall strength than a unit installed at a permanent site. Existing walls may need additional reinforcement. **NEVER RELY ON EXTERIOR SIDING OR PLYWOOD TO SUPPORT THE UNIT.** Figure 2 below represents a typical installation of a single-story stud wall at a permanent site. Since building materials and techniques vary with regions and intended use, a building contractor and/or local building code official MUST be consulted for suitable construction methods.
- Locate and attach the lower mounting bracket in the desired location on the building.
- Apply a suitable caulk across the entire length of the top rain flashing and side mounting flanges.
- Remove the flanges on both ends of the pallet and slide the unit approximately 2" off the rear of pallet. Lift unit gently into location with fork truck, taking care to align unit with lower mounting bracket.
- While allowing a small portion of weight on the lower bracket, push the unit against the wall and fasten appropriately.

### SPECIAL NOTES FOR UNIT INSTALLATION

- 1) **Minimum 12" clearance at the bottom of the unit for unrestricted airflow**
- 2) **Ensure the ambient temperature uniformity around unit**
- 3) **Intake and discharge of the outdoor air flow must not be restricted or altered**
- 4) **All insulation and sealing related to the installation must be completed properly**
- 5) **Extended Static pressure should not exceed the minimum value in the AHRI standard 390**



**FIGURE 2**



Unit Model	A	B
18/24	35	71
30/36	39	71
48/60	42	86 <sup>1</sup> / <sub>2</sub>

**MOUNTING FLANGE BOLT  
PATTERN DIMENSIONS**

## K. CONDENSATE DRAIN

A 3/4" drain hose is located on the bottom side of the unit. The drain may be extended for condensate removal to comply with local codes (use fitting size or larger). Install a condensate trap on this line.

## L. ELECTRICAL HEAT INSTALLATION

Electric heat is an option on H Series units and can be field-installed on either single- or three-phase models.

Refer to the individual installation instructions for installing heater kits.

**A TWO-STEP THERMOSTAT MUST BE USED IF AN  
ELECTRIC HEATER IS INSTALLED.**

## M. DEFROST CONTROL

The H Series units use an integrated defrost control to manage the following control functions of the system:

1. Off and on functions of the outdoor fan during the defrost and heating mode.
2. Off and on functions of the reversing valve during the defrost and heating mode.
3. Off and on functions of the auxiliary heat relays during the defrost mode.

The control is a time-and-temperature type with selectable defrost time intervals of 30, 60 and 90 minutes. Control circuit voltage at the control is 24 volts input and output. The outdoor fan relay is SPNC (single pole normally closed) and controls the fan motor.

## N. BASIC SEQUENCE OF OPERATION

### COOLING MODE

Low-voltage thermostat terminal R is connected to Y, G and O at the unit low-voltage terminal board.

The system reversing valve is energized during the cooling mode. Power is supplied to the reversing valve solenoid through the low-voltage O terminal. The low-voltage Y terminal to the control will energize the contactor latch coil (causing the contactor to energize the compressor). The low-voltage Y terminal to the control will also energize the control's timer. During the cooling mode, the defrost thermostat is open (coil temperature is above 30°F) and will not allow

the time to be accumulated to initiate the defrost mode. The outdoor fan is wired through the N/C points of the control's relay and the N/O points of the contactor. The fan motor will be energized whenever the contactor is energized (except during defrost).

### HEATING MODE

Low-voltage terminal R is connected to Y, and G at the unit low-voltage terminal board.

With the thermostat system switch turned to heat. The Y terminal will energize the contactor and outdoor fan and the G terminal will energize the indoor blower. If the thermostat does not have a separate E terminal do not jump W1 & E terminals. Wire only to W1 terminal. For more info contact technical support.

### DEFROST MODE

To prevent ice build-up on the coil during the heating mode, as the outdoor coil temperature falls below 30°F ± 5°F, an outdoor defrost thermostat closes. (This thermostat is located on a coil tube.) When the thermostat closes, the timer on the defrost control starts accumulating the compressor run time. After the selected time (30, 60, or 90 minutes) has been accumulated, the controller will start the defrost cycle regardless of the outside temperature. During the defrost cycle, the system is switched back into the cooling mode by the control de-energizing the reversing valve solenoid. The N/C pole of the control fan relay is opened, turning off the outdoor fan to allow the outdoor coil to be warmed (defrosted) faster. The defrost control energizes the indoor auxiliary heat relays through the E terminal to temper the indoor supply air. This terminal should be connected to E (second-stage heat) on the thermostat.

After the defrost thermostat reaches 60°F ± 5°F, the defrost cycle will end. The control will not allow the defrost to continue longer than 10 minutes.

### DEFROST TIME SELECTION

The defrost control has three selectable time intervals: 30, 60 and 90 minutes. The timing is factory set at 60 minutes. This timing has been determined by testing to provide the best operating efficiency. In areas where the humidity is lower than normal, the timer may be set to a higher time (90 minutes). To change the time, move the timer jumper to the post marked 30 for 30 minutes, 60 for 60 minutes, or 90 for 90 minutes.

### DEFROST TEST POST

The defrost control has test posts to speed up the defrost time setting by a factor of 256.

If you want to initiate a defrost without waiting for the time to accumulate, you can jumper the two test pins (marked test). If the coil temperature is above 30°F you will need to jumper the DFT (defrost thermostat) terminals to simulate a closed thermostat. The defrost cycle should occur in 7 seconds for a 30-minute setting, 14 seconds for a 60-minute setting, and 17 seconds for an 90-minute setting. If the jumper is removed immediately when the defrost cycle starts, the cycle will end if the defrost thermostat is opened (coil above 60°F). If the test pins remain jumped, and the defrost thermostat is closed, the defrost will end in 2.3 seconds, which is the 10-minute default.


**DURING THE ABOVE TEST, DO NOT CONTACT OR SHORT ANY  
OTHER PIN. THIS MAY DAMAGE THE CONTROL.**


## O. HIGH-PRESSURE LOCK OUT

### FIELD CHARGING

Compared to a cooling-only unit, a heat pump is difficult to field charge correctly without the use of charging scales. It is recommended the charge be weighed in with an accurate charging scale. The correct charge weight can be found on the unit name plate.

H Series units are equipped with a high-pressure switch. This switch is wired through a lockout relay to lock out the system if the high side pressure exceeds 425 psi for R22 and 600 psi for R410A. The high side pressure MUST be below 300 psi for R22 and 450 for R410A before the system can be reset.





**REPLACEABLE PARTS LIST- H SERIES WALLMOUNT HEAT PUMPS**

	PART NUMBER	DESCRIPTION	H424B1	H430B1	H430B3	H436B1	H436B3	H436B4	H448B1	H448B3	H448B4	H460B1	H460B3	H460B4
2	COMP-BZP24-001	ZP24K5EPFV130	X											
2	COMP-BZP28-001	ZP28K5EPFV130		X										
2	COMP-BZP28-003	ZP28K5ETTF5130			X									
2	COMP-BZP34-001	ZP34K5EPFV130				X								
2	COMP-BZP34-003	ZP34K5ETTF5130					X							
2	COMP-BZP34-004	ZP34K5ETFD130						X						
2	COMP-BZP44-001	ZP44K5EPFV130							X					
2	COMP-BZP44-003	ZP44K5ETTF5130								X				
2	COMP-BZP44-004	ZP44K5ETFD130									X			
2	COMP-BZP57-001	ZP54K5EPFV130										X		
2	COMP-BZP57-003	ZP54K5ETTF5130											X	
2	COMP-BZP57-004	ZP54K5ETFD130												X
7	COND-H424	COND COIL	X											
7	COND-H436	COND COIL		X	X	X	X	X						
7	COND-H460	COND COIL							X	X	X	X	X	X
8	550505	FLOWRATOR 3 CIRCUIT-COND		X	X	X	X	X	X					
8	550517	FLOWRATOR 6 CIRCUIT-COND								X	X	X	X	X
14	EVAP-VH424	EVAP COIL	X											
14	EVAP-VH436	EVAP COIL		X	X	X	X	X						
14	EVAP-VH460	EVAP COIL							X	X	X	X	X	X
15	550510	FLOWRATOR 4 CIRCUIT-EVAP	X											
15	550517	FLOWRATOR 6 CIRCUIT-EVAP		X	X	X	X	X	X					
15	550521	FLOWRATOR 9 CIRCUIT-EVAP								X	X	X	X	X
17/22	550759A	TXV VALVE 1.5-3 TON	X	X	X	X	X	X						
17/16A	550763A	TXV VALVE 4-5 TON							X	X	X	X	X	X
	061507	FILTER DRIER	X	X	X	X	X	X	X					
	061508	FILTER DRIER								X	X	X	X	X
3	2021-5008	FAN SHROUD H18-24	X	X										
3	2022-5008	FAN SHROUD H30-36			X	X	X	X	X					
3	2023-5008	FAN SHROUD H48-60								X	X	X	X	X
4	259108	MOTOR MOUNT CONDENSER FAN	X	X	X	X	X	X	X					
4	259109	MOTOR MOUNT CONDENSER FAN								X	X	X	X	X
5	0250-0025	MOTOR CONDENSER 230V 1/5 HP	X	X	X	X	X							
5	351145	MOTOR CONDENSER 230V 1/2 HP						X	X			X	X	
5	359100	MOTOR CONDENSER 460V 1/4 HP					X							
5	351146	MOTOR CONDENSER 460V 1/2 HP								X				X
6	0550-0009	FAN BLADE 20" V18-36	X	X	X	X	X	X						
6	259114	FAN BLADE 22" V48-60							X	X	X	X	X	X
9	2022-5000	ASSEMBLY LEFT SIDE PANEL H18-36	X	X		X	X							
9	2023-5000	ASSEMBLY LEFT SIDE PANEL H48-60							X	X	X	X	X	X
10	2021-5012	ASSEMBLY REAR PANEL H18-24	X											
10	2022-5012	ASSEMBLY REAR PANEL H30-36				X	X							
10	2023-5012	ASSEMBLY REAR PANEL H48-60							X	X	X	X	X	X
11	2021-5003	ASSEMBLY DIVIDER DECK H18-24	X	X										
11	2022-5003	ASSEMBLY DIVIDER DECK H30-36				X	X							
11	2023-5003	ASSEMBLY DIVIDER DECK H48-60							X	X	X	X	X	X
12	2021-5005	ASSEMBLY BLOWER PAN H18-24	X	X										
12	2022-5005	ASSEMBLY BLOWER PAN H30-36				X	X							
12	2023-5005	ASSEMBLY BLOWER PAN H48-60							X	X	X	X	X	X
13	2021-0006P	ASSEMBLY DRAIN PAN H18-24	X	X										
13	2022-0006P	ASSEMBLY DRAIN PAN H30-36				X	X							
13	2023-0006P	ASSEMBLY DRAIN PAN H48-60							X	X	X	X	X	X
1	2021-5002H	BASE PAN ASSEMBLY H24	X											
1	2022-5002H	BASE PAN ASSEMBLY H30-36		X		X	X							
1	2023-5002H	BASE PAN ASSEMBLY H48-60							X	X	X	X	X	X
18	550790	REVERSING VALVE ASSEMBLED WITH COIL	X	X	X	X	X	X	X	X	X	X	X	X
21	451988	HIGH PRESSURE SWITCH	X	X	X	X	X	X	X	X	X	X	X	X
	0445-0007	DEFROST TERMINATION STAT	X	X	X	X	X	X	X	X	X	X	X	X
22	2021-5018	BLOWER MNTG TRAY H18-24	X											
22	2022-5018	BLOWER MNTG TRAY H30-36		X	X	X	X	X						
22	2023-5018-4	BLOWER MNTG TRAY H48							X	X	X			
22	2023-5018-5	BLOWER MNTG TRAY H60										X	X	X
23	2022-5001	ASSEMBLY RIGHT SIDE H18-36	X	X	X	X	X	X						
23	2023-5001	ASSEMBLY RIGHT SIDE H48-60							X	X	X	X	X	X
23A	2023-5088	GRILL INLET RIGHT SIDE H48-60							X	X	X	X	X	X
23B	2023-5089	GRILL INLET LEFT SIDE H48-60							X	X	X	X	X	X
24	194700050002	BLOWER 9-7R DD 18, 24, & 48 CW RIGHT	X						X	X	X			
24	194700050004	BLOWER 10-7R DD 60 CW RIGHT										X	X	X
24	0500-0010	BLOWER 10-10 DD 30 & 36		X	X	X	X	X						
24	1947000050001	BLOWER 9-7L DD 48 CCW LEFT							X	X	X			
24	194700050003	BLOWER 10-7L DD 60 CCW LEFT										X	X	X
25	351115	MOTOR BLOWER 1/6 HP 230V	X											
25	1940900000006	MOTOR BLOWER 1/3 HP 230V		X	X	X	X							
25	020008	MOTOR BLOWER 1/2 HP double shaft 230V							X	X				
25	351424	MOTOR BLOWER 3/4 HP double shaft 230V										X	X	
25	359101	MOTOR BLOWER 1/3 HP 460V						X						
25	020005	MOTOR BLOWER 1/2 HP double shaft 460V									X			
25	351426	MOTOR BLOWER 3/4 HP double shaft 460V												X
26	258972	MOTOR MOUNT INDOOR ASSY H24	X											
26	258972	MOTOR MOUNT INDOOR ASSY H30-36		X	X	X	X	X						
26	258976	MOTOR MOUNT INDOOR ASSY H48-60							X	X	X	X	X	X
27	2021-5007	TOP H18-24	X											
27	2022-5007	TOP H30-36		X	X	X	X	X						
27	2023-5007	TOP H48-60							X	X	X	X	X	X
28	2021-5010	TOP FRONT PANEL H18-24	X											
28	2022-5010	TOP FRONT PANEL H30-36		X	X	X	X	X						



**REPLACEABLE PARTS LIST- H SERIES WALLMOUNT HEAT PUMPS**

28	2023-5010	TOP FRONT PANEL H48-60								X	X	X	X	X	X
29	2021-5011	MIDDLE FRONT PANEL (no fresh air) H18-24	X												
29	2021-5011E	MIDDLE FRONT PANEL (economizer f/a) H18-24	X												
29	2021-5011F	MIDDLE FRONT PANEL (barometric f/a) H18-24	X												
29	2022-5011	MIDDLE FRONT PANEL (no fresh air) H30-36		X	X	X	X	X							
29	2022-5011E	MIDDLE FRONT PANEL (economizer f/a) H30-36		X	X	X	X	X							
29	2022-5011F	MIDDLE FRONT PANEL (barometric f/a) H30-36		X	X	X	X	X							
29	2023-5011	MIDDLE FRONT PANEL (no fresh air) H48-60							X	X	X	X	X	X	X
29	2023-5011E	MIDDLE FRONT PANEL (economizer f/a) H48-60							X	X	X	X	X	X	X
29	2023-5011F	MIDDLE FRONT PANEL (barometric f/a) H48-60							X	X	X	X	X	X	X
30	2021-5014	LOWER CONDENSER PANEL H18-24	X												
30	2022-5014	LOWER CONDENSER PANEL H30-36		X	X	X	X	X							
30	2023-5014	LOWER CONDENSER PANEL H48-60							X	X	X	X	X	X	X
31	2022-5062	DISCONNECT ACCESS DOOR H18-60	X	X	X	X	X	X	X	X	X	X	X	X	X
31A	070518	BREAKER DOOR LATCH H18-60	X	X	X	X	X	X	X	X	X	X	X	X	X
32	659942	AIR FILTER DISPOSABLE 16x25x1 H18-36	X	X	X	X	X	X							
32	659943	AIR FILTER DISPOSABLE 16x25x2 H18-36	X	X	X	X	X	X							
32	659926	AIR FILTER DISPOSABLE 20x30x1 H48-60							X	X	X	X	X	X	X
32	659924	AIR FILTER DISPOSABLE 20x30x2 H48-60							X	X	X	X	X	X	X
33	654602	ALUMINUM FILTER 5x30x.025 H18-60	X	X	X	X	X	X	X	X	X	X	X	X	X
34	2021-5004	FILTER RACK H18-24	X												
34	2022-5004	FILTER RACK H30-36		X	X	X	X	X							
34	2023-5004	FILTER RACK H48-60							X	X	X	X	X	X	X
35	2022-5021	HEATER MOUNTING PLATE H18-36	X	X	X	X	X	X							
35	65SM1007-F	HEATER MOUNTING PLATE H48-60							X	X	X	X	X	X	X
36	EGH05B1-HP	FIELD INSTALL HEAT KIT 5 KW 1 PHASE 230V	X	X		X			X				X		
36	0430-0074	HEATER 5KW 1P 240V	X	X		X			X				X		
36	EGH10B1-HP	FIELD INSTALL HEAT KIT 10 KW 1 PHASE 230V	X	X		X			X				X		
36	0430-0072	HEATER 10 KW 1P 240V	X	X		X			X				X		
36	EGH15B1-HP	FIELD INSTALL HEAT KIT 15 KW 1 PHASE 230V	X	X		X			X				X		
36	0430-0074	HEATER 5 KW 1P 240V	X	X		X			X				X		
36	0430-0072	HEATER 10 KW 1P 240V	X	X		X			X				X		
36	EGH06B3-HP	FIELD INSTALL HEAT KIT 6 KW 3 PHASE 230V					X			X				X	
36	458009	HEATER 6 KW 3P 240V					X			X				X	
36	EGH09B3-HP	FIELD INSTALL HEAT KIT 09 KW 3 PHASE 230V					X			X				X	
36	458010	HEATER 09 KW 3P 240V					X			X				X	
36	EGH18B3-HP	FIELD INSTALL HEAT KIT 18 KW 3 PHASE 230V					X			X				X	
36	458013	HEATER 18 KW 3P 240V					X			X				X	
36	EGH06D4-HP	FIELD INSTALL HEAT KIT 6 KW 3 PHASE 460V						X			X				X
36	458015	HEATER 6 KW 3P 460V						X			X				X
36	EGH09D4-HP	FIELD INSTALL HEAT KIT 09 KW 3 PHASE 460V						X			X				X
36	458016	HEATER 09 KW 3P 460V						X			X				X
36	EGH15D4-HP	FIELD INSTALL HEAT KIT 15 KW 3 PHASE 460V						X			X				X
36	458020	HEATER 15 KW 3P 460V						X			X				X
37	2022-HEPL	HEATER EXTENSION PLATE H24-36	X	X		X	X	X							
37	2023-HEPL	HEATER EXTENSION PLATE H48-60							X	X	X	X	X	X	X
38	454332	SWITCH LIMIT 245F One Shot	X	X		X	X	X	X	X	X	X	X	X	X
38	454323	SWITCH LIMIT 160-30F 240 W/Fuse	X	X		X	X	X	X	X	X	X	X	X	X
39	2021-5009H	BOX CONTROL V18-24	X												
39	2022-5009H	BOX CONTROL V30-36			X	X	X	X							
39	2023-5009H	BOX CONTROL V48-60							X	X	X	X	X	X	X
40	2021-5017	COMPRESSOR ACCESS DOOR H18-24	X												
40	2022-5017	COMPRESSOR ACCESS DOOR H30-36		X	X	X	X	X							
40	2023-5017	COMPRESSOR ACCESS DOOR H48-60							X	X	X	X	X	X	X
41	2021-5020	BLOWER CUT OFF SHIELD H18-24	X												
41	2022-5020	BLOWER CUT OFF SHIELD H30-36		X	X	X	X	X							
41	2023-5020-4	BLOWER CUT OFF SHIELD H48							X	X	X				
41	2023-5020-5	BLOWER CUT OFF SHIELD H60										X	X	X	X
42	2022-0015	PLATE TOP INSUL PROTECT H/V30-36	X	X	X	X	X	X	X	X	X	X	X	X	X
<b>ELECTRICAL COMPONENTS PARTS LIST</b>															
	453150	COMP CONTACTOR 1 POLE 1P 25 AMP	X	X			X			X					
	453770	COMP CONTACTOR 2 POLE 1P 40 AMP											X		
	453772	COMP CONTACTOR 3 POLE 3P 25 AMP				X		X		X	X			X	X
	452842	PHASE MONITOR				X		X			X	X		X	X
	0400-0031	COMP CAPACITOR 10/80@370											X		
	450368	COMP CAPACITOR 7.5/40@370	X												
	450370	COMP CAPACITOR 7.5/45@370		X			X								
	450378	COMP CAPACITOR 10/70@370							X						
	450325	BLWR CAPACITOR 10@370									X				X
	450205	BLWR CAPACITOR 7.5@370	X			X		X	2	X	2	X	X	2	X
	160500730145	BLWR CAPACITOR 7.5@440			X	X	X	X							
	451000	TERMINAL BLOCK	X	X	X	X	X	X	X	X	X	X	X	X	X
	452752	TRANSFORMER 208/240V 50VA 24V	X	X	X	X	X	X	X	X	X	X	X	X	X
	452756	TRANSFORMER 480V 50VA 24V						X							X
	452200	FAN RELAY	X	X	X	X	X	X	X	X		X	X	X	X
	0821N-0084A	FAN RELAY						X			X				X
	042004	CIRCUIT BREAKER 2 POLE 1P 60 AMP 240V	X	X		X		X	X		X	X			X
	453807	CIRCUIT BREAKER 3 POLE 3P 60 AMP			X		X			X				X	
	451955	DISCONNECT KIT 460V							X				X		
	451956	DISCONNECT KNOB 460V							X				X		
	452195	LOCKOUT RELAY	X	X	X	X	X	X	X	X	X	X	X	X	X
	451995	DEFROST CONTROL BOARD	X	X	X	X	X	X	X	X	X	X	X	X	X
	0415-0028	LOW VOLTAGE TERMINAL BOARD	X	X	X	X	X	X	X	X	X	X	X	X	X
	451049	JUMPER BAR ASSEMBLY													
	451840	OPTION BOARD													
	454388	LOW PRESSURE SWITCH													
	451992	FAN CYCLE SWITCH													

\*Part Numbers are Subject to Change


## H Series Heat Pumps Electrical Data

Model No. & Electric Heater Kw [1]	VOLT/ PHASE 60 Hz	NO. OF FIELD POWER CKTS.	SINGLE-FIELD CIRCUIT				DUAL-FIELD CIRCUIT							
			MCA	MOP[2]	FIELD POWER WIRE SIZE [3]	GROUND WIRE SIZE [3]	MCA		MOP [2]		FIELD POWER WIRE SIZE [3]		GROUND WIRE SIZE [3]	
							CKT1	CKT2	CKT1	CKT2	CKT1	CKT2	CKT1	CKT2
<b>H424B00A1</b> <b>5</b> <b>10</b>	208-230/1	1 1 1 OR 2	19 45 70	30 50 80	14 8 4	10 10 8	19	52	30	60	14	6	10	10
<b>H424B00A3</b> <b>6</b> <b>9</b>	208-230/3	1 1 1	19 37 46	30 40 50	14 8 8	10 10 10								
<b>H430B00A1</b> <b>5</b> <b>10</b>	208-230/1	1 1 1 OR 2	24 50 76	40 60 80	12 6 4	10 10 8	24	52	40	60	12	6	10	10
<b>H430B00A3</b> <b>6</b> <b>9</b>	208-230/3	1 1 1	24 42 50	40 50 60	12 8 6	10 10 10								
<b>H436B00A1</b> <b>5</b> <b>10</b>	208-230/1	1 1 1 or 2	26 52 78	40 60 80	10 6 4	10 10 8	26	40	40	60	10	8	10	10
<b>H436B00A3</b> <b>6</b> <b>9</b>	208-230/3	1 1 1	20 39 48	30 40 50	12 8 8	10 10 10								
<b>H436B00A4</b> <b>6</b> <b>9</b>	460/3	1 1 1	10 19 23	15 20 25	14 14 12	14 12 10								
<b>H448B00A1</b> <b>5</b> <b>10</b>	208-230/1	1 1 OR 2 1 OR 2	33 59 85	50 70 90	10 6 3	10 8 8	33 33	26 52	50 50	30 60	10 10	10 6	10 10	10 10
<b>H448B00A3</b> <b>6</b> <b>9</b>	208-230/3	1 1 1	24 42 50	30 50 60	12 8 6	10 10 10								
<b>H448B00A4</b> <b>6</b> <b>9</b>	460/3	1 1 1	10 20 25	15 25 30	14 12 10	14 10 10								
<b>H460B00B1</b> <b>5</b> <b>10</b>	208-230/1	1 1 OR 2 1 OR 2	39 65 90	60 80 100	8 4 3	10 8 8	39 39	26 52	60 60	30 60	8 8	10 6	10 10	10 10
<b>H460B00B3</b> <b>6</b> <b>9</b>	208-230/3	1 1 1	26 44 53	40 50 60	10 8 6	10 10 10								
<b>H460B00B4</b> <b>6</b> <b>9</b>	460/3	1 1 1	13 22 27	20 25 30	14 12 10	12 10 10								






- LEGEND - CURRENT 02/04/15
- COMP - COMPRESSOR  
DC - DUAL CAPACITOR  
DFS - DEFROST SENSOR  
DFT - DEFROST TSTAT
- EHLR - ELECTRIC HEAT LOOKOUT RELAY  
FR - FAN RELAY  
HPS - HIGH PRESSURE SWITCH  
PH - PHASE MONITOR
- IBM - INDOOR BLOWER MOTOR  
LDR - LOCK-OUT RELAY  
DFM - OUTDOOR FAN MOTOR  
LPS - LOW PRESSURE SWITCH
- RC - RUN CAPACITOR  
RVC - REVERSING VALVE CONTROL  
RVS - REVERSING VALVE SOLENOID

ECONOMIZER SOCKET DESIGNATION



USE HIGH SPEED FOR COOLING  
USE MEDIUM SPEED FOR HEATING  
USE LOW SPEED FOR HEATING ON TWO SPEED MOTORS




FOR ECONOMIZER USE, JUMPER MUST BE REMOVED


FOR FIRESTAT USE, JUMPER MUST BE REMOVED

\*CLASS 2\*

HEATER SOCKET DESIGNATION




SEE RESISTANCE HEAT DIAGRAM IF APPLICABLE




SEE CONTROL OPTION DIAGRAM IF APPLICABLE

NO OPTION PLUG



Test  
90  
60  
30



DEFROST CONTROL 45-1995

ENERGIZED IN COOLING

COMP

DFS

RVC

RVS

DFT

BK

Y

BR

R

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

162

163

164

165

166

167

168

169

170

171

172

173

174

175

176

177

178

179

180

181

182

183

184

185

186

187

188

189

190

191

192

193

194

195

196

197

198

199

200

201

202

203

204

205

206

207

208

209

210

211

212

213

214

215

216

217

218

219

220

221

222

223

224

225

226

227

228

229

230

231

232

233

234

235

236

237

238

239

240

241

242

243

244

245

246

247

248

249

250

251

252

253

254

255

256

257

258

259

260

261

262

263

264

265

266

267

268

269

270

271

272

273

274

275

276

277

278

279


280

281

282



283

284




USE HIGH SPEED FOR COOLING  
USE MEDIUM SPEED FOR HEATING

USE HIGH SPEED FOR COOLING  
USE MEDIUM SPEED FOR HEATING





FOR ECONDMIZER USE, JUMPER  
MUST BE REMOVED


FOR FIRESTAT USE, JUMPER  
MUST BE REMOVED






'CLASS 2'



SEE  
CONTROL  
OPTION  
DIAGRAM  
IF  
APPLICABLE

HEATER SOCKET  
DESIGNATION

SEE RESISTANCE  
HEAT DIAGRAM  
IF APPLICABLE



460 VOLT AC, 3 PHASE, 60 HZ SUPPLY


COLOR CODE	
BK	BLACK
BL	BLUE
BD	BROWN
GR	GREEN
GY	GREY
DR	DRAWN
OR	ORANGE
PK	PINK
PU	PURPLE
RD	RED
WH	WHITE
YL	YELLOW



- CDMP - COMPRESSOR  
 DC - DUAL CAPACITOR  
 DFS - DEFROST SENSOR  
 DFT - DEFROST T-STAT
- EHLR - ELECTRIC HEAT LOCKOUT RELAY  
 FR - FAN RELAY  
 FPM - FAN PRESSURE SWITCH  
 PH - PHASE MONITOR
- IBM - INDOOR BLOWER MOTOR  
 LOR - LOCK-OUT RELAY  
 OFM - OUTDOOR FAN MOTOR  
 LPS - LOW PRESSURE SWITCH
- RC - RUN CAPACITOR  
 RVC - REVERSING VALVE CONTROL  
 RVS - REVERSING VALVE SOLENOID

DRAWING NO. 1220-0014-0000 REV C DRAWING APPLIES TO  
 BASIC HEAT PUMP SYSTEM H460B004XXXX-XX  
 460/3/60

ECONOMIZER SOCKET DESIGNATION



IBM SOCKET DESIGNATION



USE HIGH SPEED FOR COOLING  
 USE MEDIUM SPEED FOR HEATING  
 USE LOW SPEED FOR HEATING ON TWO SPEED MOTORS


OPTION SOCKET DESIGNATION




FOR ECONOMIZER USE, JUMPER MUST BE REMOVED

FOR FIRESTAT USE, JUMPER MUST BE REMOVED


\*CLASS 2\*





HEATER SOCKET DESIGNATION










SEE RESISTANCE HEAT DIAGRAM IF APPLICABLE



SEE CONTROL OPTION DIAGRAM IF APPLICABLE



460 VOLT AC, 3 PHASE, 60 HZ SUPPLY




COLOR CODE	
BK - BLACK	
BL - BLUE	
BR - BROWN	
G - GREEN	
GR - GREY	
D - DRANGE	
P - PINK	
PU - PURPLE	
R - RED	
Y - YELLOW	

OPTIONAL ACCESSORIES MAY OR MAY NOT BE FACTORY INSTALLED.

## UNIT DIMENSIONS

MODEL	A	B	C	D	E	F	G	H	I	J	K	L	M	N	P	Q	R	S	T	U	V	W	X	Y	Z
24	36	34	18 <sup>5</sup> / <sub>8</sub>	28 <sup>1</sup> / <sub>16</sub>	12	20 <sup>1</sup> / <sub>2</sub>	8	1 <sup>7</sup> / <sub>8</sub>	20	28 <sup>9</sup> / <sub>16</sub>	1 <sup>1</sup> / <sub>8</sub>	71 <sup>1</sup> / <sub>2</sub>	2 <sup>1</sup> / <sub>2</sub>	10 <sup>1</sup> / <sub>2</sub>	18 <sup>1</sup> / <sub>2</sub>	26 <sup>1</sup> / <sub>2</sub>	34 <sup>7</sup> / <sub>8</sub>	1 <sup>1</sup> / <sub>8</sub>	16	32	1 <sup>15</sup> / <sub>16</sub>	2 <sup>9</sup> / <sub>16</sub>	29 <sup>1</sup> / <sub>2</sub>	27 <sup>1</sup> / <sub>8</sub>	27 <sup>5</sup> / <sub>8</sub>
30/36	40	38	18 <sup>5</sup> / <sub>8</sub>	28 <sup>1</sup> / <sub>2</sub>	14	18	8	1 <sup>7</sup> / <sub>8</sub>	28	28 <sup>9</sup> / <sub>16</sub>	1 <sup>1</sup> / <sub>8</sub>	71 <sup>1</sup> / <sub>2</sub>	2 <sup>1</sup> / <sub>2</sub>	10 <sup>1</sup> / <sub>2</sub>	18 <sup>1</sup> / <sub>2</sub>	26 <sup>1</sup> / <sub>2</sub>	39	1 <sup>1</sup> / <sub>4</sub>	18 <sup>1</sup> / <sub>4</sub>	36 <sup>3</sup> / <sub>8</sub>	2	2 <sup>9</sup> / <sub>16</sub>	29 <sup>1</sup> / <sub>2</sub>	27 <sup>1</sup> / <sub>8</sub>	31 <sup>5</sup> / <sub>8</sub>
48/60	43 <sup>1</sup> / <sub>8</sub>	41	24	27 <sup>1</sup> / <sub>2</sub>	16	30	10	2 <sup>1</sup> / <sub>4</sub>	30	36 <sup>1</sup> / <sub>2</sub>	1 <sup>1</sup> / <sub>8</sub>	87	2 <sup>1</sup> / <sub>2</sub>	10 <sup>1</sup> / <sub>2</sub>	18 <sup>1</sup> / <sub>2</sub>	26 <sup>1</sup> / <sub>2</sub>	42	1 <sup>1</sup> / <sub>8</sub>	19 <sup>3</sup> / <sub>4</sub>	39 <sup>1</sup> / <sub>2</sub>	6 <sup>1</sup> / <sub>2</sub>	3 <sup>3</sup> / <sub>4</sub>	29 <sup>1</sup> / <sub>2</sub>	27 <sup>1</sup> / <sub>8</sub>	33 <sup>1</sup> / <sub>2</sub>



## RATED INDOOR AIR FLOW RATE

SIZE	18	24	30	36	48	60
CFM	670	800	1250	1250	1800	2100



---

The information in this manual supersedes and replaces the previous instruction/operation manual 67862 8-H with regards to HV Series wallmount products. Illustrations, part numbers and others cover the general appearance of the units at the time of publication and the manufacturer reserves the right to make changes in design and construction at any time without notice.

For replacement parts contact:

National Coil Company  
1998 FM 2011  
Longview, TX 75603  
Phone: 903-643-2261  
Fax: 903-643-2222