

# ULTRA FAUCET INSTALLATION

## BEFORE YOU BEGIN

We recommend consulting a professional if you are unfamiliar with installing plumbing fixtures. Signature Hardware accepts no liability for any damage to the faucet, plumbing, sink, counter top, or for personal injury during installation.

Observe all local plumbing and building codes.

Unpack and inspect the faucet for shipping damage. If any damage is found, contact our Customer Relations team at 1-866-855-2284.

## GETTING STARTED

- Ensure that you have gathered all the required materials that are needed for the installation.
- For these instructions, it is assumed that the old faucet has been completely removed and any necessary repairs or modifications to the water supply have been completed.

## TOOLS AND MATERIALS:



Plumber's  
Tape



Thread  
Sealant



Phillips  
Screwdriver



Adjustable  
Wrench




Small  
Bucket


## INSTALLATION

1. Ensure that the water supply below your sink is shut off.

**Tip:** Place a small bucket below your workspace to catch any water that may drip during the installation process.




2. Remove the lock nuts, metal washer, and rubber washer from the faucet's mounting posts.




# ULTRA FAUCET INSTALLATION


3. Insert the faucet into its prepared mounting hole. Once in position, slide the rubber washer followed by the metal washer back onto the faucet's mounting posts. Secure the faucet using the lock nuts. Tighten firmly using the provided basin wrench.



4. Attach the main supply lines to the braided water lines on the faucet. Ensure that the hot and cold lines are connected as marker. Apply plumber's tape or thread sealant to the threads before tightening. Hand tighten the connections, then finish tightening with an adjustable wrench. Be very careful not to overtighten.



5. Once installation is complete, turn the main water supply back on from underneath your sink. Check for any leaks underneath.



6. Turn the faucet on for approximately 60 seconds to check for any leaks. Ensure that both hot and cold water are functioning properly.

