# Rinnai


# PERFORMANCE DATA

### **To Obtain Performance Data:**

- Press and hold the (Down) button for two seconds
- While holding the \(\bigcup \)(Down) button, press and hold the "Indirect Tank" button (hold both buttons at the same time) (Fig 1).

3. Use the (Up) and (Down) buttons to scroll to

- the desired information described in Table 1. Performance Data (Fig 2).
- 4. The data for the performance number automatically appears in the display (Fig 3).
- 5. To exit performance data, repeat step 2 above.



# 11 120 +4 MODE ▶ ▲ ▶ ✓

**Setting Description** 

his parameter is available when DIP switch 1 is in the OFF (default) position. This sets the maximum outdoor temperature the boiler will fire in CH mode.

#	Data	Unit
O۱	Water Pressure	PSI/bar <sup>1</sup>
33	Supply Temperature	°F/°C¹
04	Return Temperature	°F/°C¹
05	Freeze Protection Temperature	°F/°C¹
06	Exhaust Temperature	°F/°C¹
#	Fan Frequency	Hz
17	Venturi Position	0=Closed, 1=Open
18	Venturi Cycles	x100
20	Pump Cycles	x100

imp for System (Pump 1) 0=OFF, 1=ON

#	Data	Unit
24	Pump for Indirect Tank (Pump 2)	0=OFF, 1=O
30	Indirect Tank Thermistor Temperature	°F/°C <sup>1</sup>
31	Outdoor Temperature	°F/°C <sup>1</sup>
40	Energization Hours	x100
Ч	Combustion Hours	x10
42	Combustion Cycles	x100
45	Commissioning Cycles	x1

See "Units of Measurement" section to the right.

## **Units of Measurement**

- 1. Press the "Mode" button
- Press the (Up) or (Down) arrows to select a unit of measurement (refer to Table 2).

### Table 2. Units of Measurement

Units of Measurement	Temp.	Water Flow	Pressure
1: English	°F	gal/min	psi
2: Metric	°C	L/min	bar

# **ELECTRICAL DIAGNOSTICS**

Table 3. Diagnostic Points					
COMPONENT	WIRE COLOR	VOLTAGE	RESISTANCE	PC	В
COMPONENT	WINE COLOR	VOLINGE	RESISTANCE	Connector	PIN
Power Supply	Black-White	108-132 VAC	N/A	CN24	1-3
Flame Rod	Yellow-Body	More than 2 VAC <sup>2</sup>	N/A	CN1	2
Spark Electrode	Red-Black	11-14 VDC <sup>2</sup>	N/A	CN1	11-22
	Red-Black	7-48 VDC <sup>2</sup>	N/A	CN1	3-5
Combustion Fan	White-Black	2-14 VDC <sup>2</sup>	N/A	CN1	5-9
	Yellow-Black	11-14 VDC	N/A	CN1	5-7
	Blue-White	N/A	22,420	CN1	17-19
	Yellow-Red (No.9)	N/A	33-43Ω	CN1	13-15
Venturi Control Device	Black-Red (No.3)	11-14 VDC		CN1	11-29
	Black-Brown	Close Position: Less than 1 VDC Open Position: 4-6 VDC	N/A	CN1	26-29
	Black-Grey	Close Position: 4-6 VDC Open Position: Less than 1 VDC		CN1	24-29
Gas Solenoid Valve	Yellow-Black	11-14 VDC <sup>2</sup>	15-25Ω	CN1	28-30
Exhaust Thermistor	White-White		59°F: 11.4-14kΩ 86°F: 6.4-7.8kΩ	CN11	16-19
Supply Thermistor	White-White		113°F: 3.6-4.5kΩ	CN11	12-19
Return Thermistor	White-White	N/A	$140^{\circ}F: 2.2-2.7k\Omega$ $221^{\circ}F: 0.6-0.8k\Omega$ Disconnect the connector and measure at thermistor side.	CN11	10-20
Freeze Protection Thermistor	Black-Black		32°F: 38k-43k 50°F: 22k-26k 68°F: 14k-17k Disconnect the connector and measure at thermistor side.	CN11	10-14
T	White-Grey	108-132 VAC	11/4	CN18	1-2
Transformer	Red-Red	20-30 VAC (possible to measure at Output terminal as substitute position)	N/A	CN18	3-4
Overheat Switch	Black-Black	Less than 1 VDC	Less than $1\Omega$	7(CN11)-2	27(CN1)
Water Barrery Course	Red-Black	11-14 VDC	N/A	CN1	11-29
Water Pressure Sensor	Yellow-Black	0 kPa: 655-745 mV; 200 kPa: 2,155-2,245 mV; 400 kPa: 3,655-3,745 mV	N/A	6(CN11)-2	9(CNH1)
Water Level Electrode	White-White	11-14 VDC	N/A	8(CN11)-2	29(CN1)
Air Handler	Red-Black	11-14 VDC	N/A	CN8	1-2
Control Panel	Black-Black	11-14 VDC	N/A	CN2	1-4

# **Important Safety Notes**

There are a number of (live) tests required when performing electrical diagnostics on this product. Proceed with caution at all times to avoid contact with energized components inside the boiler. Only trained and qualified service technicians should attempt to repair this product. Before checking for resistance readings, disconnect the power source to the unit and isolate the item from the circuit (unplug it).

## **Electrical Diagram**

Refer to the Wiring Diagram attached to the back of the boiler front cover.


# Flame Rod

Place one lead of your meter to the flame rod and the other to the ground. When the unit is attempting to ignite, you should read more than 2 VAC.

### Amp Fuses

This unit has two (10) amp glass fuses located on the PC Board Remove the fuses and check continuity through it. If you have continuity through each fuse then it is functioning. Otherwise, the fuse is blown and must be replaced

# **DIP SWITCHES**



### Table 4 DIP Switch Functions

Selection

Curve 3

60 Minutes

No

Curve 2

30 Minutes

77°F (25°C)

Yes


Curve 1

#	DIP Switch Function
1	Outdoor Temperature Sensor: Enables or disables outdoor temperature sensor.  OFF (Default): Outdoor Temperature Sensor in Use  ON: Outdoor Temperature Sensor Not in Use
2	Thermostat Usage: Changes mode between Thermostat Usage and Central Heating (CH) Button.  OFF (Default): Thermostat Used  ON: CH button used. Boiler fires based on return water temperature
3	Indirect Tank: Enables the Indirect Tank Function for Pump 2.  OFF (Default): On

	Indirect Tank Thermistor/Thermostat Selection: Selects the method of controlling the indirect tank. OFF (Default): Thermistor; ON: Thermostat
	Gas Valve Solenoid: Manually shuts down the integrated solenoid gas valve.  OFF (Default): Normal Operation; ON: Fixed Closed (prevents boiler operation)
	Altitude Setting: Sets the appropriate elevation of the boiler installation.  OFF/ON: Depends on Altitude. See "Table 5. High Altitude DIP Switches" for specific DIP

- **Altitude Setting:** Sets the appropriate elevation of the boiler installation. OFF/ON: Depends on Altitude. See "Table 5. High Altitude DIP Switches" for specific DIP
- Vent Type Selection: Selects the venting material used. The boiler is set from the factor, to be installed in a PVC venting system. If CPVC, PP, or other approved venting is used, this setting may be adjusted. See Section 5 in Manual for more information OFF (Default): PVC
- ON: Higher Temperature Exhaust Vent Material (PP, CPVC, or Stainless Steel)

Curve 4



Record date and parameter when individual parameters have been adjusted factory

Date Adjusted Parameter Value

Table 5. High Altitude DIP Switches												
ALTITUDE	DIP Switch 6	DIP Switch 7										
0-2,000 ft (0-610 m) (Default)	OFF	OFF										
2,001-5,400 ft (610-1,646 m)	ON	OFF										
5,401-7,700 ft (1,646-2,347 m)	OFF	ON										
7,701-10,200 ft (2,347-3,109 m)	ON	ON										

	ON: Outdoor Temperature Sensor Not in Use
2	Thermostat Usage: Changes mode between Thermostat Usage and Central Heating (CH) Button.  OFF (Default): Thermostat Used  ON: CH button used. Boiler fires based on return water temperature
3	Indirect Tank: Enables the Indirect Tank Function for Pump 2.  OFF (Default): On  ON: Off (Pump 2 Operates at a CH Zone Pump)
4	Indirect Tank Thermistor/Thermostat Selection: Selects the method of controlling the indirect tank. OFF (Default): Thermistor; ON: Thermostat
5	Gas Valve Solenoid: Manually shuts down the integrated solenoid gas valve.

- switch settings.

Parameter Value

# **To Display Diagnostic Codes:**


# Press and hold the Indirect Tank button for two seconds and then the (Up) button simultaneously (Fig 9).

**DIAGNOSTIC CODES** 

The last nine maintenance codes display and flash one after the other.

To exit diagnostic codes and return the boiler to normal operation, press and hold the "Indirect Tank"

button simultaneously.



Check sensor wiring for damage.

Replace if necessary.

High/Low Water Pressure

Low Water Cut-Off (LWCO)

Solenoid Valve Circuit

Combustion Fan

PC Board circuit errorReplace PC Board.

PC Board

Measure the voltage of the sensor.

Pressure Sensor

Power Reset Heat Exchanger Overheat (140), Venturi Control (150), High Exhaust Temperature (540), and Freeze issue (880) can be reset by shutting down power to the boiler. Venturi (170) and Solenoid Valve Circuit (520) can be reset by pushing and holding button SW1 and 2 for five seconds.

Other Reset Other error can be reset by Indirect Tank "On/Off" button or "Central Heating" (CH) button.

If the water pressure is too low, add water into the system until at least 13 PSI is observed.

Ensure there are no leaking components in the CH system.

If the pressure is too high, adjust the pressure to a maximum of 30 PSI.

Ensure the LWCO jumper is connected properly when LWCO is not in use. Ensure the output is 24 VAC on the PCB. If it is not, check the transformer harness and output of transformer.

Measure the resistance of the exhaust thermistor.<sup>3</sup>
If the sensor has been replaced and the error still appears, check the return

Ensure the pressure relief valve and water fill are working correctly.
 Ensure deaeration has been performed.

Ensure the LWCO device is working correctly.

Check the flame rod and wire for damage.

Ensure the flame rod and wire are not wet.

Check the exhaust thermistor wiring for damage. Clean the surface of the thermistor.

Check the exhaust duct, seal, and venting for damage.

Measure resistance and voltage of motor wire harness.
 Ensure the combustion fan spins freely.

Check the motor wire harness for loose or damaged connections.

Close the gas shut off valve installed near the boiler.

Check the output from the PC Board to the solenoid gas valve.
If the output from the PC Board is abnormal, replace the PC Board.
If the output from the PC Board is normal, replace the gas control.

High Exhaust Temperature

## Table 8. Diagnostic Codes

### Air Supply or Exhaust Blockage/Condensate Trap is Full Fan current initial check error. Ensure condensate line and trap is not blocked.

- Ensure internal air filter is clean with no obstructions.
- Ensure high altitude setting is set properly (See Table 5. High Altitude DIP Switches).
- Ensure combustion air and exhaust vents are not blocked and the approved venting materials are being used.
   Ensure either the exhaust ring or intake cap is removed properly.

- Ensure vent length is within limits.
   Check fan for debris and ensure wheel turns freely.

# Verify fan check valve is not stuck between fan casing and burner body.

- No Ignition (Unit Not Turning On) Ignition Error.
  Check that the gas is turned on at the boiler, gas meter, and/or propane cylinde
- If the unit is installed in a propane system, ensure that gas is in the tank. Bleed all air from the gas lines. Check the ground wire for the PC Board. Ensure the flame rod wire is connected
- Ensure the igniter is operational. Ensure the venting is installed in accordance with the I-Series Boiler Installation and Operation Manual.
- Check that the surface of the electrode and flame rod are clean
- Check gas solenoid valves for open or short circuits.
- Verify gas orifice installed is correct for the gas system the unit is installed in.
   Check flame rod voltage to ground during ignition.

- Flame Failure
- Boiler has flame failure. Check that the gas is turned on at the boiler, gas meter, and/or propane cylind
- - If the unit is installed in a propane system, ensure that gas is in the tank.
    Ensure the venting is installed in accordance with the I-Series Boiler Installation and Operation Manual.
    Ensure the flame rod wire is connected.
  - Ensure the gas type and inlet gas pressure are correct. Bleed all air from the gas lines.
  - Check the ground wire to the PC Board.
     Check flame rod voltage to ground during ignition
  - Heat Exchanger Overheat
  - Overheat switch is tripped.

  - Measure the resistance of the Overheat Switch.

    Check the heat exchanger surface for hot spots which may indicate blockage due to scale buildup. • Ensure the boiler pump is not locked up.

  - Ensure that all of the valves in the CH circuit are open.
     Ensure the boiler and CH circuit does not have a freezing condition.
  - The surface of the heat exchanger may turn to a black color as stainless steel is tempered even in normal conditions. This does not indicate an abnormal condition.
  - Check for damage on the exhaust, seal, and venting. Ensure the parameter A0 corresponds to the gas type the unit is installed in.
  - Ensure the gas orifice is the proper orifice for the gas type in use.
  - Ensure deaeration has been performed.

    Venturi Control

    Venturi Control
  - Venturi operation error.
     Ensure the venturi motor is operating correctly.<sup>3</sup>
  - Replace the gas valve assembly.
  - Venturi Blockage Check the venturi and silencer for blockage.
  - Before resetting this error, check if the condensate drain is blocked and if the venting is connected properly.
  - Indirect Tank Temperature
  - Indirect tank runs for more than six hours without cycling off.
  - Ensure the tank size is adequate.
  - Check the thermistor location. Ensure the system is plumbed properly

  - Check the supply temperature for tank is higher than tank setting temperature (Parameter 30).
  - Check sensor wiring for damage Measure resistance of sensor
  - Replace sensor if necessary Electrical Grounding
  - Secondary circuit ground fault.
  - Check all electrical components for electrical short.
  - Condensate Pump (Accessory)
  - Boiler will operate for 60 seconds. Confirm wire connections and harnesses are good.
  - Ensure the condensate reservoir is empty and condensate pump is operational Freeze Protection Thermistor
  - Check sensor wiring for damage. Measure the resistance of the sensor
  - Replace if necessary.
  - Supply Thermistor Check sensor wiring for damage
  - Clean the surface of the sensor. Measure the resistance of the sensor
  - Check the return thermistor. Replace if necessary.
  - Check sensor wiring for damage. Measure the resistance of the sensor.
  - Replace if necessary. Indirect Tank Thermistor
  - Ensure DIP switch 4 is set to the appropriate setting. Check sensor wiring for damage. Measure the resistance of the sensor.
  - Replace if necessary. Exhaust Thermistor
  - Check sensor wiring for damage
     Clean the surface of the sensor. Measure the resistance of the sensor • Check the return thermistor.
  - Replace if necessary. Outdoor Thermistor
  - Ensure that DIP switch 1 is set to the appropriate position
  - Check sensor wiring for damage. Measure the resistance of the sensor Replace if necessary.

<sup>3</sup> See "Electrical Diagnostics" section of this document.

**PARAMETER SETTINGS** 

PC Board

When the unit is operating.

five seconds (Fig 5).

- Solenoid Valve Circuit Ensure Dip switch 5 on the PC Board is in the OFF position (default). Ensure the gas control wire is not loose or damaged. Replace the PC Board.
- Flame Rod Check the flame rod and wire for damage. Ensure the flame rod and wire are not wet.
- If there is no issue with the flame rod or wiring, replace the PC Board. Freeze Issue
- The boiler checks the heat exchanger temperature at the time of operation. If the temperature is too low, an error will occur
- Check if there is freezing in the boiler or CH system.
- PC Board Mismatch This code occurs when the PC Board and the internal logic do not match.
- Check if the software versions of the board and operation board do not match
- This code is a placeholder in diagnostic code history indicating a service provider performed maintenance or service.
- Enter this code after performing service by pressing the following buttons at the same time: UP, DOWN, and Indirect Tank. "FFF" appears on the monitor




Fig 10. "Up." "Down" and "Indirect Tank" Button.

# Code Boiler does not start heating with a heating demand present.

- Supply temperature or return temperature inside the boiler may be too hot. Ensure the pump operates properly.
- The boiler does not operate with the CH setting button.
- If DIP switch 2 is OFF, CH operation will function via the room thermostat. Boiler does not start heating the indirect tank, although the indirect tank is calling
- After the tank priority time (Parameter 34) passes, the boiler will be in heatin priority for 60 minutes. Supply Temperature is different from the setting temperature on the controller.
- During outdoor sensor control, the supply temperature will vary dependent or the outdoor temperature. During simultaneous operation of an Indirect Tank and CH, the supply temperature for CH is based on Indirect Tank control.
- No Code CH capacity is insufficient
  - During simultaneous operation of an Indirect Tank and CH, flow volume to heating can be reduced.
- No Code Pump or fan is operating even with no demand
  - The boiler may start or operate the pump for freeze protection operation.

The pump may intermittently operate to prevent it from becoming stuck.


06/2020 800000133(02)

button on the PC Board or the "Mode" button on the controller. For more information on parameter settings, refer to the I-Series Condensing Boiler


33

Press the "Mode" button on the controller (Fig 6). Press the (Up) or (Down) arrows to select a parameter setting. Press the

To access the parameter settings, press and hold the red button on the PC Board for



Press the (Up) or (Down) arrows to change the selection for the setting



number (such as 30-A or 30-b). Then, press the "Select" button (Fig 8).

sure Indication on the Control Panel. The current pressure will cycle on the controller display. This parameter is available when Dip Switch 1 is in the OFF (default) position. Select the proper curve from below. **Curve 1**: Standard baseboard, high efficiency air handler, cast iron or panel radiators. **Curve 2**: Staple-up radiant heat. **Curve 3**: High temperature air handler or undersized baseboard. **Curve 4**: Custom curve based on customer input. his parameter is available when Dip Switch 1 is in the OFF (default) position. Boost Mode increases the CH set temperature above the outdoor reset urve target when the boiler has been running on an unusually long call for heat.

imum Outdoor Temperature at which the Boiler will Fire in CH Mode.






Fig 7. "Up," "Down" and "Select" Buttor Fig 6. "Mode" Button





Installation and Operation Manual.






Models         Gas Type         Kit Number           i150S         i120S         NG/LPG         803000040
NG/LPG
NG/LPG
i090S
i060S







210	200	207	206	205	204	203	202	200	156	154	153	152	151	147	146	145	136	131	121	120	119	118	117	116	115	114	113	111	110	107	106	105	102	101	100	046	045	044	040	017	016	015	010	008	007	004	003	ITEM
Flue Connection Assembly	Combustion Analysis Port Cap	Thermistor Screw	Exhaust duct seal	O-ring	Thermistor	Exhaust Duct Packing	O-ring	Exhaust duct Assv	Electrode sleeve	Electrode Plate	Electrode packing	Flame Rod	Electrode	n tube	Band RC98HPi/e, Cond drain tube, bottom KT	Condensate Trap Assembly	OHS Bracket	Heat Exchanger Assembly-madium	Noise filter	O-ring	Inlet Gas Test Port Screw	Inlet Gas Supply Connection	Gas tube Bracket	Gas connection pipe Assy	O-ring ,	Gas Valve Assembly With Orifice	Hexagon Head Screw	Fan mounting packing	Combustion Fan Assembly	Burner Plate Assembly-medium	Burner Gasket-medium	Rurner Assembly-medium	Burner Plate Assembly-Large	Burner Gasket-Large	Burner Assembly-Large	Front Panel Packing-side	Front Panel Packing-Top	Screw Cover	Front name   Assy	Grounding Screw	Igniter Assembly	Igniter Bracket	Residential Screw and Washer	Rubber Bushing	Connection Reinforcement Plate	Upper Wall Mount Bracket	Lower Wall Mount Bracket	DESCRIPT
108000083				107000323	105000235									807000176	109000138			807000174					109000635	806000054			^	109000611	108000081	806000052	109000610	806000051		109000609					7			109000599		Þ	809000165		109000281	PART NUMBE
	2 H	-		1 1	1 1		_		_				1 1				1	-	+				1 1	1 1	2 2		-	1 11	1 1			<b>⊢</b>		1 1	1 1								4 c			1 1	1 1	i150S i120S
H H	با د	حا د	۲ ۱	1	ъ	н г	)	<u> </u>	<b>-</b>	<b>⊢</b>	-	<b>ы</b>	₽	ъ	2	н і	<b>-</b>	۷	F	2	2	Ь	1	1	2	ъ (	υ F	٦ ٢	Ь	1	<b>L</b>	<b>→</b> ⊢	۷			2	2	2 -	۱ د	۲ ۲	۱ د	<b>1</b> N	4 c	. ω	1	1	1	i090S
	<u>با</u> د	4		1	1	н г	4		- 1	- 1	1	<u> </u>	_	1				د	-		-		1	1	2			<u> </u>	1	1		<b>→</b>	۷									7 /		+	1	1	1	i060S
804 Screw 805 Screw	803 Screw			800 Screw	_	719 Igniter Ground Harness		-	716 OVER HEAT SWITCH				_			_	705 Transformer		_			472 O-ring			-+		451   Fipe Blacket	_	446 Primary-Secondary Pipe Assy-Medium	-		442 Air vent		440 HEX-CH Heating Connection Pipe	-	_		420 CH Heating Return Pine Assembly	-	-+-		222 Air Supply Carlot 3 inch	+	+	215 Air supply pipe seal ring	213 Exhaust Gasket - 2 inch	212 Exhaust pipe connection port - 2 inch	DESCRIPT
109000178		^	CP-30583	109000746	809000176	105000243	80500000 805000001	\$0500000 102000203	105000000	805000093	\$05000095	105000238	805000094	805000093	809000184	805000092	\$0500086 109000838	100000628	809000173	807000207	807000205	807000204	807000215	805000080	805000079	809000170	809000169	807000202	807000201	807000200	807000199	807000198	807000197	807000196	807000195	807000193	807000210	807000209	907000709	807000185	807000182	108000087	108000086	108000085	108000017	109000623	108000084	PART NUMBE
w u	7		-	4 4		<u> </u>					_				-		1 U		2 2		2 2	11 11	2 2		-		) L	) <u>1</u>				_		1 1	1 1					-		→ ⊢ -		1	1 1	1 1		i150S i120S
υ			2	4	1	H H	٦ ٢	۱ د	۱ د	٦ ٢	۱ د	<u></u> Р	ا د	<b>1</b>	<u>ب</u>	<u> </u>	ں د	n	2	1	2	10	2	1	1	<u> </u>	7 F	۷ .	1		<b>1</b>	- L	٦ ٢	1	1		<b>1</b>	<b>→</b>  -	۲ ۲	1 ^	<b>)</b>	٦ ٢	٠ ١	Ь	1	1		i090S
n (r	, 15	ω	2	4	ㅂ	<b>-</b>	-	۲ ۲	_    -	<b>→</b>	_    -	<b>⊢</b>	ı ا د	<b>⊢</b>	<u>⊢</u>	<b>⊢</b>	<u> -</u> ا د	n	2	<u> </u>	2	10	2				χ Q	• <u>∞</u>	1 8			× ×		1 8.	1 8.	∞		→ F				o o		1 8	1 8	1 8	1 8	i060S
																							-	Installation a	User Manual	Technical Da	889 Installation and Operation Manual		863 Pressure Relief Valve	LP Conversic		860 Wall Bracket		827 Screw					SCLENIA SCLENA			814 SCIEW		811 Screw	810 Screw	808 Screw	807 Screw	DESCRIPT
																											800000114		807000211			109000628		809000181								TC9000611K					U217-449	PART NUMBER
																								1 1				1 1	1 1	1 1		->   F		2 2						_		၁ ဝ	-		8			i150S i120S
																							F				+	-	-	$\vdash$			+	<del>  -     -       -     -</del>	$\vdash$				ئا د		11	+	-	+	1			