

INSTALLATION INSTRUCTIONS

Shut Off Water Supply

1. Note position of the stop and the body.
2. Remove handle, bonnet, stem assembly, seats and springs. Discard old stem and seats, but keep the springs.
3. Place springs and new seats, with the smallest end of the spring inside the seat into the body. Insert new stem unit with the stop facing the correct way, and secure with the bonnet.
4. Secure the handle. Turn on water supplies and flush for one minute.
BE SURE COLD WATER FLOWS FIRST.
5. The rotational limit stop must be adjusted so that the maximum temperature flowing out the valve is 120°F or less. This stem is not factory preset.

INSTRUCCIONES DE INSTALACIÓN

Cierre el suministro de agua.

1. Anote la posición del tope y cuerpo.
2. Retire el mando, el bonete, el ensamble del eje, los asientos y los resortes. Descarte el eje usado y los asientos, pero conserve los resortes.
3. Coloque los resortes y los asientos nuevos, con el extremo mas pequeño del resorte dentro del asiento en el cuerpo. Inserte el eje con el tope en la posición correcta y asegure con el bonete.
4. Asegure el mando. Abra el suministro de agua y deje correr por un minuto.
ASEGURESE DE DEJAR CORRER PRIMERO EL AGUA FRÍA.
5. El tope límite rotacional debe ajustarse a una temperatura máxima de 120°F o menos. Este eje no está pre-ajustado.

