



## Ball Assembly for Single Handle Lever Faucets (Except Monitor<sup>®</sup>, Scald Guard<sup>®</sup>, Delta<sup>®</sup> Mix, Slow Close & Pull-Out Faucets).

Shut Off Water Supply. 1. Remove handle.  
2. Unscrew adjusting ring, remove cap assembly.  
3. Remove cam and ball assemblies.  
4. Reinstall new ball assembly with cam and  
packing. 5. Install cap assembly hand tight,  
then tighten adjusting ring, until no water will  
leak around stem when faucet is 'on'. 6. Check  
for leaks. Replace handle.

## Rotule Pour Robinets à Une Manette.

Interrompez L'Alimentation en Eau. 1. Enlevez la manette.  
2. Desserrez l'anneau de réglage et enlevez le chapeau.  
3. Tirez sur la tige de la rotule pour enlever la came et la  
rotule. 4. Montez la rotule neuve avec la came et la  
garniture d'étanchéité. 5. Montez le chapeau et serrez-le  
à la main, puis serrez l'anneau de réglage, jusqu'à ce que  
l'eau cesse de fuir autour de la tige lorsque le robinet est  
ouvert. 6. Vérifiez l'étanchéité. Remettez la manette.

Ensamblaje de la Bola para Llaves de  
Una Sola Manija. Cierre el Suministro de Agua.  
1. Quite el mando. 2. Afloje el aro de ajuste, quite  
el ensamble de la tapa. 3. Quite los ensambles de la  
leva y bola. 4. Reinstale la bola nueva con la leva y  
el empaque. 5. Instale la tapa apretando a mano,  
luego apriete el aro de ajuste, hasta que el agua no  
se filtre por alrededor del eje, cuando la llave de  
agua está abierta. Fíjese si hay fugas. Coloque  
el mando otra vez

Made in/Fabrique a/Hecho en: USA

