

WASTE & OVERFLOW WASHER

Installation Instructions:

1. Unscrew faceplate and pull faceplate and lift rod assembly through hole in tub.
2. Reach in through access door (usually provided behind tub) and remove old washer.
3. Slip new washer over overflow pipe flush with tub wall.
4. Replace lift rod assembly and faceplate; screw tight.

ARANDELA DEL REBOSADERO

Instrucciones de instalación:

1. Desenrosque la placa frontal y tirar de la misma junto con la varilla elevadora para sacar el mecanismo por el agujero de la bañera.
2. Retire la arandela existente desde atrás de la bañera (la puerta de accesonormalmente se encuentra detrás de la bañera).
3. Pase la arandela nueva por el caño de rebalse y dejarla contra la pared de la bañera.
4. Volver a introducir el mecanismo de varilla y la placa frontal; ajustar firmemente.

