

## INSTRUCTIONS FOR PUSH BUTTON DIVERTER FITS MOEN®

**Note:** Your faucet may not match illustration.

1. Turn off water to faucet.
  2. Remove decorative cap (A) by prying it off carefully using a small tool.
  3. Unthread screw (B) to remove handle (C).
  4. Remove two screws (D) that hold flange (F) in place.
  5. Remove sleeve (E) and flange (F)
  6. Using wrench turning counter-clockwise, remove push button diverter (G) from faucet body (H)
  7. Reassemble faucet with new part in reverse order, check for leaks before installing flange (F)
- Note: Be sure spacer ring (I) is in place before reinstalling handle.

## INSTRUCCIONES PARA EL AJUSTE DEL DERIVADOR MEDIANTE PULSADOR MOEN®

**Nota:** Es posible que su grifo no coincida con la ilustración.

1. Cierre el agua del grifo.
2. Retire la tapa decorativa (A) haciendo palanca con cuidado con una herramienta pequeña.
3. Desenrosque el tornillo (B) para quitar la manija (C).
4. Quite dos tornillos (D) que sujetan la brida (F) en su lugar.
5. Retire el manguito (E) y la brida (F).
6. Con una llave y girando hacia la izquierda, retire el desviador del botón pulsador (G) del cuerpo del grifo (H).
7. Vuelva a ensamblar el grifo con la pieza nueva en orden inverso. Verifique que no haya fugas antes de instalar la brida (F).

Nota: Asegúrese de que el anillo espaciador (I) esté en su lugar antes de volver a instalar la manija.

