



INSTALLATION INSTRUCTIONS

1. Rockford solids interceptors should be installed as close as possible to the fixture being serviced, and upstream of the grease interceptor. Always leave sufficient room for cleaning maintenance.
2. Install the P-Trap upstream of the solids interceptor.
3. The outlet piping should match that of the solids interceptor.
4. The static water level in the unit is a line between the bottom of the inlet to the bottom of the outlet.

NOTE: All interceptors must be installed per local codes.

