

Bathtub Trim Kit with Snap-On Faceplate

NOTE: Compatible with Jones Stephens' quick test style bath waste kits

Parts List

1. Stopper Assembly
2. Spud
3. Drain Gasket
4. Faceplate

NOTE: Depending on the model, package includes faceplate and drain or faceplate and stopper.

Additional Parts Needed

- Pliers

Installation Instructions

1. To install the faceplate (No. 4), snap it onto the existing retainer nut, making sure that the slot is facing downward.

Note: Faceplate (4) may exhibit a loose fit on the retainer nut, before being installed on the tub. The thread pattern on the overflow elbow is tapered and will expand the outside diameter of the nut to provide a more secure fit during the installation process. You can tighten the retainer nut an additional 1/8 to 1/4 turn if the faceplate is still loose after installation.

2. To install the stopper assembly (No. 1), insert it into the existing drain.
3. To install the drain (Nos. 2-3), place the drain gasket (No. 3) underneath the tub and screw the drain spud (No. 2) into the existing drain elbow, through the drain gasket (No. 3). You can use a pliers to help install the spud.

