

## Installation Recommendations for HDPE Meter Boxes/Meter Pits Stacking Boxes/Pits & Using Extensions:

1. Measure base of hole to ground level at each end. Cut extension to correct height noting the lid area is 1.75" deep.
2. Stack boxes or pits to a greater height than measurement, cut off base of riser box/pit to correct height and or angle.
3. Use 2 screws on each side as depicted when stacking boxes or pits. This provides much greater strength against side loads and is easier to set grade when boxes or pits are in the ground, they won't pull apart allowing dirt into the lid area. Use 2 screws on each side for the 11-18 and 13-24 extensions and 3 screws each side on the 15-27 and 17-30 extensions.
4. Place boxes in meter pit and backfill.  
**DO NOT PLACE LARGE ROCKS (1 1/2") IN BACKFILL OR NEXT TO BOX/PIT.**

**NOTE: FOLLOW INSTALLATION RECOMENDATIONS.**

5. **DO NOT ALLOW DRIVE-BY** equipment around boxes or pits until the soil has dried.

