

Installation Instructions



PF42850, PF42851, PF42870, PF42871

Roof Drains (fits over pipe)

Installation Instructions

1. Read all instructions carefully prior to installation.
2. Flashing Attachment
Install single ply membrane, soft copper lead or BUR felt flashing between clamping ring and drain flange.
3. PVC 4" Connector
When joining PVC plastic together, the use of a primer and PVC or All-purpose cement is required. Under all conditions allow proper drying of PVC connector to drain before attaching expansion coupling.
4. Accessory Tightening Procedure
When joining PVC plastic together, the use of a primer and PVC or All-purpose cement is required. Under all conditions allow proper drying of PVC connector to drain before attaching expansion coupling.
5. Coupling Hook up
Attaches to Schedule 40 DWV plastic or No Hub cast iron drain line.
6. Special Note
Wet or damaged insulation or insulation with low compressive strength should be removed around drain flange seating area and replaced with insulation having a minimum compressive value of 25 PSI – this rating or higher should apply to all of the above roofing conditions. Drain should have insulation tapered to it; allowing complete drainage through weep holes of clamp device.
7. PF42859 – Under deck mounting kit

Before purchase and use of a product, please review the product application and be certain the product, installation and use will be in compliance with any applicable codes and regulations.

Warranty and Codes

This PROFLO product carries a 1-year limited warranty.

