

## TOOL REQUIRED

- Flat-blade screwdriver
- Phillips screwdriver

## INSTALLATION

1. Carefully remove the plug button from the handle.
2. Loosen the screw, and remove the handle from the valve.
3. Use a flat-blade screwdriver to carefully pry the insert and spline adapter off the valve stem. Discard the insert and spline adapter.
4. Press the replacement spline adapter on the valve stem. **Partially** press the replacement insert onto the spline adapter. **Do not** press the insert all the way onto the spline adapter at this time.
5. Slowly fit the handle on the insert, and check the handle alignment. If the handle is not properly aligned, remove the handle and insert. Then carefully remove the spline adapter, and turn it one spline tooth in the direction needed. Press the spline adapter onto the valve stem. Partially install the insert, and check the handle alignment again. Repeat these steps as necessary until the handle alignment is correct.
6. When the handle alignment is correct, remove the handle. Press the insert all the way onto the spline adapter. Install the handle, and secure it in place with the screw.
7. Press the plug button into the handle.

