

---

## Water Supply Kit- How to Use

---

1. Install the self tapping saddle valve on the cold water copper tubing so that the outlet is in a convenient direction.
2. Tighten screws evenly-brackets should be parallel. Tighten firmly do not over tighten.
3. Connect plastic tubing to self tapping saddle valve outlet.
4. Coil a minimum of 8 ft. Tubing (3 turns 10-in. diameter) behind refrigerator. This will allow refrigerator to be moved away from wall for cleaning or service.
5. Cut tubing length required and make connection at refrigerator.
6. Turn the self-tapping saddle valve handle clockwise until you feel it is firmly seated. Note: you have now pierced the copper tube and the valve is closed.
7. Turn the valve counter clockwise to open the valve.
8. Check all connections for leaks.