INSTALLATION INSTRUCTIONS CARE AND MAINTENANCE

American Standard

Style That Works Better

Princeton[™] Bath Models: 2390.202, 2391.202, 2392.202, 2393.202

Thank you for selecting American Standard - the benchmark of fine quality for over 100 years. To ensure this product is installed properly, please read these instructions carefully before you begin. (Certain installations may require professional help.) Also be sure your installation conforms to local codes.

Observe Local Plumbing and Building Codes

1 FRAMING INSTRUCTIONS 762mm (30)ш LEVELING SUPPORT STRINGER 51 x 102mm Note recess is 1527 x 762mm ഗ (60-1/8 x 30). Cut a 229 x 305mm (2 X 4) (9 x 12) hole in sub floor for drain, centered 362mm (14-1/4) as shown 229 x 305mm for below floor rough. Locate studs (9 x 12) FLOOR CUTOUT as required, then ensure rough ш FOR DRAIN opening dimensions are proper and ſ supports are plumb and square. * Install stringer as shown (346mm [13-5/8] for through the floor drain or 435mm [17-1/8] for above the floor drain.) ENOTH $\langle q \rangle$ ы. œ 1527mm (60-1/8)0 ш. ш 2 3 DRAIN INSTALLATION > The tub is provided with an integral base for easier installation. Position the bath on the floor and slide ∢ into place until the tub is resting on the rear stringer. The base does not need to contact the floor for Install the overflow and proper installation. The base on the 2392 and 2393 models is raised above the floor to facilitate drain S drain assembly onto the installation. Check level, front to back and side to side. Also check drain clearance hole in sub floor. To tub per manufacturer's secure the tub to wood studs, use roofing nails immediately above the flange of the tub. To secure the instructions. tub to steel studs, use drywall screws and flat washers. UNDERLAYMENT (See Step 4) FINISHED TILE FLOOR Caution: Take Extra Care When Driving Nails or Screws To Avoid Damaging NAIL The Tub. OR DRYWALL The tile or similar SCREW finished floor will be EVERY STUD butted against the bottom of the tub apron also holding Į the tub in place. SUB FLOOR



For service under these warranties, it is suggested that a claim be made through the contractor or dealer from or through whom the product was purchased, or that a service request (including a description of the product model and of the defect) be sent to the following address:

Ecatepec 55540 Edo. Mexico www.americanstandard.com.mx

Toll Free: (800) 387-0369

www.americanstandard.ca

For residents of the United States, warranty

the following toll free number: (800) 442-1902 www.americanstandard-us.com