

# Technical Data Sheet

Rev: 04-2018

## Product Description

QSR provides a system for the rehabilitation of concrete or masonry benches and inverts and the repairing of voids in concrete or masonry substrates prior to the application of Strong-Seal® products. QSR is a rapid-setting, hand-mixed, hand-applied calcium aluminate cement product blended with pozzolans, lightweight aggregate, alkaline-resistant fiberglass reinforcement, and performance enhancing admixtures used to form a patching material or monolithic liner. QSR is specifically formulated for applications with a pH of 2.0 or higher.

## Performance Specifications

Compressive Strength: (ASTM C109)

>1,500 psi	1 Hour
>2,000 psi	24 Hours
>3,000 psi	28 Days

Bond Strength: (ASTM C882)

>2,000 psi	28 Days
------------	---------

Drying Shrinkage: (ASTM C596)

0%	28 Days @ 90% RH
----	------------------

Working Time:

5 to 15 minutes

Final Set:

15 to 30 minutes

Wet Unit Weight: (ASTM C138)

105 ± 5 lb/ft<sup>3</sup>

Packaging:

50 lb bag / 40 bags per pallet

40 lb pail / 42 pails per pallet

Yield per Bag / Pail:

0.57 ft<sup>3</sup> / 13.8 ft<sup>2</sup> @ ½" thick (Bag)

0.46 ft<sup>3</sup> / 11.0 ft<sup>2</sup> @ ½" thick (Pail)

## Typical Structures

QSR provides repairs to concrete and masonry benches and inverts and repairs voids in the following structures:

Manholes	Tunnels & Pipelines
Tanks & Containment	Wastewater Facilities

## Equipment

Approved application equipment includes a clean pail or bowl and gloved hands, spoon, trowel, or handheld drill for mixing. If using other equipment, please contact The Strong Company, Inc.

## Surface Preparation

Insert plug into or bypass incoming connections. Remove all foreign material and laitance from the substrate using a high pressure water spray (minimum 3000 psi). Remove loose and protruding brick, mortar, and concrete using a mason's hammer, chisel and/or scraper.

Stop active leaks using an instant-setting, specially formulated product per manufacturer's recommendations. Some leaks may require weep holes to localize the infiltration during the application. After application, the weep holes shall be plugged with the instant-setting product prior to final pass.

When severe infiltration exists, pressure grouting may be required. Follow manufacturer's recommendations when pressure grouting.

## Mixing

Use 4.0 to 5.0 fluid ounces of water per pound of product. Add the required amount of water to the pail/bowl first, followed by product. Mix by hand/spoon/trowel/drill until consistency allows for application of up to one inch thick without material "sagging" on a vertical surface. Only mix amounts that can be applied within 15 minutes. Use the minimum amount of water to achieve desired consistency. Follow all other manufacturer's recommendations.

## Application

Confirm substrate is clean and free of all foreign material and is damp without noticeable free water droplets or running water prior to application.

For invert repair: quickly and firmly apply by hand/trowel up to one (1) inch thick in one or more passes starting from the bottom of invert; however, minimum total thickness shall not be less than ½ inch.

For bench repair: quickly and firmly apply by hand/trowel to bench so that a gradual slope is produced from the walls to the invert or center of the bench. Provide a ½ inch minimum thickness at the invert or center. Round the wall/bench intersection to a uniform radius.

For void repair: quickly and firmly apply by hand or trowel so that void is filled completely.

Trowel the surface to a smooth finish being careful not to over trowel. Apply a wet brush finish to the troweled surface.

## Curing

Take care to minimize exposure of applied material to sunlight and air movement. Cover the structure if application of additional passes is to be longer than 15 minutes. Do not expose to sunlight or air movement for longer than 15 minutes before covering or closing access. Shade the structure in hot and arid climates during application. Keep the applied material damp for the first 72 hours if the humidity level is below 70%. An ASTM C309 curing compound may be used in lieu of keeping material damp.

Hold times for the final application are as follows: storm run-off and surcharge - two (2) hours; force main impact - four (4) hours

## Weather

Do not apply if ambient temperature is below 40°F. Do not apply to frozen surfaces or if substrate is expected to freeze within 24 hours after application. Keep the material temperature at time of application below 90°F. Do not allow water temperature to exceed 80°F. Chill with ice if necessary.

## Acceptance

Cast four 2 inch cube specimens each day or for every pallet of material used, whichever occurs first. Properly package, label, and return specimens to the manufacturer for testing in accordance with the owner's or manufacturer's directions for compressive strength per ASTM C109.