

STEP 1:

Pre-drill a 5/8" hole with a regular drill or hole saw.

STEP 2:

Insert SST screw into #14 black nut driver. With wing nut and washer on bolt, insert wing nut thru surface, and begin installation.

STEP 3:

When bolt is secure and nut driver spins free, stop drill motor and remove.

STEP 4:

SST screw is now ready to receive 1/4" or 3/8" all thread rod or bolt stock.