

# INSTRUCTION GUIDE

## PLUMBER'S PUTTY



- 1** Open lid on container and remove desired amount of putty to complete your application
- 2** Make sure to put lid back on container to keep debris from entering the container and mixing with clean putty
- 3** Knead putty in hands until soft and pliable and form into a rope (roughly ½" thick)
- 4** Place the rope of putty around the underside of the product's flange that you are installing, making sure to blend the two ends together where they meet
- 5** Install your product (e.g. bath waste, shower drain, pop-up or basket strainer) as you secure your product into place, the excess putty will ooze out from under the flange
- 6** Remove excess putty after the product is properly secured and wipe clean
- 7** If putty is being used in colder applications, wait 10 minutes after the initial installation and confirm the product doesn't need a little extra turn to properly secure
- 8** Excess putty can be blended back into the container as long as it is still clean and free of debris

