

HOW TO

Install a Solvent-Weld Shower Drain



STEP 1
Secure shower drain to shower floor. Use silicone sealant for water tight seal.



STEP 2
Tighten locking nut to secure shower drain to shower floor.



STEP 3
Measure distance from floor to stop inside of shower drain. Cut pipe to measured height.



STEP 4
Apply solvent cement to secure shower drain and pipe.

HOW TO Replace A Shower Strainer



STEP 1
Remove old strainer by using a flat-head screwdriver to pry loose from shower drain, if a snap-in strainer. Use Philips-head screwdriver to remove screws if a screw-in strainer.



STEP 2
Insert new strainer by snapping into shower drain.