

Sym	Revisions	Date	Ву

Clean and bevel pipe before the gasket is stretched onto the OD as shown. If needed, stainless clamps placed in grooves. As pipe is placed into MH wall, center gasket in wall cut—out, support pipe, pack cut—out with proper grout, backfill after it has fully set—up.

Typical Installation of the Vertite Waterstop Gasket.

4"-12" Profile shown.

