CABLE TOOLS

 $\mathsf{RIDGID}^{\circledast}$ offers a wide variety of cutters and augers to clean everything from grease to root blockages. With the <code>RIDGID</code> line of cable tools, you will always have the right tool for the job.



C-12, C-14, C-15, C-31, C-32, C-33, C-44, C-45, and C-46 & all IW Cables.



(TOOLTIP)

Always start with a straight auger to try and determine what you are trying to clean. Then chose the correct cutter to clear the drain.

DROP HEAD AUGER

For cleaning back to back mounted fixtures e.g., sinks where cable needs to be led into down pipe.





RETRIEVING AUGER

For searching for cable which is broken or lost in line.





SPIRAL SAW TOOTH CUTTER

For clearing any stoppage, roots, rags, sticks, etc.





GREASE "C" CUTTER

For grease blockage in lines leading from garbage disposal unit or waste pipe.





STRAIGHT AUGER

SPADE CUTTER

SAW TOOTH CUTTER

locking.

For cleaning lines blocked heavily with

roots. Unique design permits cutter to

For use in exploring and breaking up stoppages or returning sample to surface to determine correct tool.





For following up after augers have been

used and to open up floor drains.

FUNNEL AUGER

For use as second tool in line. Breaks up remains of stoppage left by straight auger.





HOOK AUGER

For heavy and dense root stoppages in pipes that require hooking and breaking up.





GREASE CUTTER

For lines which have become badly greased with detergents and have to be opened.





SHARKTOOTH CUTTER

For use in cleaning pipes of general material clinging to pipe walls.





EXPANDING FINISH CUTTERS For final removal of material adhering to walls and certain roots of fibrous nature.





For use when vigorous action is required for cleaning of scale in pipes and boiler tubes.





FLUE BRUSH For use for finish cleaning required of boiler tubes and heat exchangers.





800.769.7743 | RIDGID.com

FOUR BLADE SAW TOOTH CUTTER For blockages caused by hardened, glazed material such as chemical deposits.





SPIRAL BAR CUTTER

For main sewers blocked by roots, leaf debris, sticks, sawdust, cloth, and sacking.







be removed from damaged pipe without