

HOW TO

Install a Solvent-Weld Shower Drain



STEP 1



Secure shower drain to shower floor. Use silicone sealant for water tight seal.

STEP 2



Tighten locking nut to secure shower drain to shower floor.

STEP 3



Measure distance from floor to stop inside of shower drain. Cut pipe to measured height.

STEP 4



Apply solvent cement to secure shower drain and pipe.

HOW TO Replace A Shower Strainer



Remove old strainer by using a flat-head screwdriver to pry loose from shower drain, if a snap-in strainer. Use Philips-head screwdriver to remove screws if a screw-in strainer.



Insert new strainer by snapping-into shower drain.