22.44 [570.00]

28.43 [722.00]

1) Determine direction mirror will be hung.

2) Measure distance from hooks to top of frame. In order for mirror to hang level these distances should be equal. If they are not equal, accommodations need to be made in placement of mounting hardware.

3) Determine desired location for top of frame on wall. Measure down this will locate position of mounting hardware.

4) Using a level and a pencil, gently draw a line on wall at that point. If level is not available, at two points from ceiling measure distance from ceiling to frame plus frame to hooks. Connect points with straight edge.

5) Measure hooks from point to point. Mark those locations on line (reference step 4) and install appropriate mounting hardware such as wood screws, toggle bolts, plastic anchors etc. . .

6) Slip hooks over mounting hardware.

Ⓐ   Ⓑ

(A)   2   #6 SCREWS
(B)   2   #6 PLASTIC WALL ANCHORS

KICHLER.