



Assembly Instruction For 10003

1. Attach the crystal shades (*B*) to the sockets (*A*) then secure by socket rings (*C*).
2. Install the bulbs (*D*) to the sockets (*A*).

