




Extension Kits for ACCUFIT™ Tub and Shower Valves
Model ACF3001EXTCP,
ACF3001EXTBN,
ACF3001EXTORB



You may need



Hex Allen Wrench

To install a deep rough extension kit on an ACCUFIT rough in valve:

Step 1 – Install brass cartridge stem extension (part #3) using a hex wrench to tighten both set screws (part #4).

Step 2 – Screw the brass valve extension (part #2) onto the top of the existing valve sleeve.
 Tighten with pliers or crescent wrench.

Step 3 – Slide longer trim sleeve (part #1) over the extended valve sleeve.

Step 4 – Install trim kit as normal using longer faceplate screws (part #6).

