

Installation Instruction For 24303

It is recommended that this fixture be installed by a licensed electrician.

- 1. Turn off breaker at electrical panel
- 2. Assemble part(C) into coupler (A) till tighten
- 3. Assemble tube with nipple(M) into coupler (B) till tighten, and place the glass pipe(D1) to the tube(M) using with glass ball(D)
- 4. Place the tube(F) on the socket(E);
- 5. Hang the crystal(H) on each arm(G),(I),(J);
- 6. Hang the crystal (L) on the cup(K);
- 7. Install 60 watt bulbs into sockets.

Warning!!! lamps burn extremely hot. Turn fixture off and allow bulbs to cool at least 15 minutes before touching.

