

AQUAPHALT™

Permanent pothole repair material for asphalt + concrete

YOU CAN INSTALL IN 3 SIMPLE STEPS:

1



- **NOTE:** For best compaction, you will need a hand-tamper or roller.
- Gather a broom, shovel or rake, water and a hand-tamper or roller.
- Begin by using a broom to remove all loose material from the area to be repaired, and sweep it clean. In icy conditions, remove all ice from the area.

2



- Pour the Aquaphalt directly into your patch area. Unlike other patching products, Aquaphalt is free flowing for ease in placement and leveling.
- Level your material with a shovel or a rake so it sits roughly an inch above the adjacent area to account for compaction.

3



- Saturate the Aquaphalt with water. Aquaphalt's green binder reacts and hardens with only water.
- Compact to a smooth finish with a hand-tamper, vibratory plate or roller. If the compacted material is below the level of the surrounding pavement, simply spread more Aquaphalt, pour more water and recompact.
- When complete, simply rinse area clean.



Using Aquaphalt is as simple as that: Pour into the damaged area, saturate with water, and compact. And because Aquaphalt begins to harden right away, roadways can be open to traffic immediately. It looks professional, binds with only water and begins to set-up immediately. A permanent repair safe for pets, family and the environment!

Use your smart phone or iphone scan tool for how-to videos and more!

www.aquaphalt.com

Instrucciones en Español
al reverso