**Precision Plumbing Products** "Specify with Confidence - Install with Pride"

## **INSTALLATION FLUID HAMMER ARRESTORS**

www.pppinc.net


- 1. Flush line prior to installation.
- 2. Only use teflon tape to seal the pipe thread.
- 3. To tighten place wrench on hex only.
- 4. For best results locate arrestor as close to the quick closing valve as possible.
- 5. Either a verticle or horizontal installation is acceptable.
- 6. See product catalog for recommended pressure rating.

7. Failure to follow these instruction will make null and void the product warranty.

## RECOMMENDED ROUGH-IN OF PPP WATER HAMMER ARRESTORS.

Arrestors should always be installed so that there is an unobstructed shock path to the arrestor. Doing otherwise could result in shake and rattle of the pipes when the valve is closed.

Arrestors should always be placed as near to the source of shock as possible - one each on the hot and cold water lines.



## **Precision Plumbing Products**



<u>|lindustries, inc.</u>

Division of JL Industries, Inc.

Airport Business Center 802 SE 199th Ave. Portland, Oregon 97233

T (503) 256-4010 F (503) 253-8165 MERICAN GLOBAL STANDARDS 1400 GREEN CERTIFIED-GREEN CERTIFIED-

MI-WHA-05 Rev 06/09

www.pppinc.net