

## VALVE BOX ADAPTOR II INSTALLATION PROCEDURES

# ADAPTOR

### Step One

Identify the valve type (AFC, Mueller, Kennedy, Clow, EJ, etc.) and size (2" to 16"). Then select the proper Valve Box Adaptor II (VBA-II) to match the valve.



### Step Two and Three

Insert VBA-II into the bottom of the valve box and push down until securely in place.



### Step Four and Five

Place valve box and VBA-II onto bonnet of valve, push down until securely in place.



CALL OR VISIT OUR WEBSITE TO LEARN MORE

2151 South 54th Street, West Allis, WI 53219 • office 414.764.6733 • fax 414.764.1494 • [adaptorinc.com](http://adaptorinc.com) •  American Made