



D'MAND KONTROLS® Button  
**HWB-CH-S**  
(Standard non-lighted)



Drill a 5/8" hole in the face of the cabinet where the D'MAND KONTROLS® pump is installed. Next, feed the two wire cable through the 5/8" hole; connect the hard-wired button to the two lead cables. (Red and Black) The hard-wired button has two (2) terminals to affix a wire on each side.



Once the wires are firmly connected, you can firmly press the round button into the hole until secure.

Please refer to our website at [www.gothotwater.com](http://www.gothotwater.com) for warranty and indemnification information.



D'MAND KONTROLS® Button  
**HWB-CH-S**  
(Standard non-lighted)



Drill a 5/8" hole in the face of the cabinet where the D'MAND KONTROLS® pump is installed. Next, feed the two wire cable through the 5/8" hole; connect the hard-wired button to the two lead cables. (Red and Black) The hard-wired button has two (2) terminals to affix a wire on each side.



Once the wires are firmly connected, you can firmly press the round button into the hole until secure.

Please refer to our website at [www.gothotwater.com](http://www.gothotwater.com) for warranty and indemnification information.



D'MAND KONTROLS® Button  
**HWB-CH-S**  
(Standard non-lighted)



Drill a 5/8" hole in the face of the cabinet where the D'MAND KONTROLS® pump is installed. Next, feed the two wire cable through the 5/8" hole; connect the hard-wired button to the two lead cables. (Red and Black) The hard-wired button has two (2) terminals to affix a wire on each side.



Once the wires are firmly connected, you can firmly press the round button into the hole until secure.

Please refer to our website at [www.gothotwater.com](http://www.gothotwater.com) for warranty and indemnification information.