

INSTALLATION INSTRUCTIONS  
SHOWERHEAD ASSEMBLY  
MODEL NO. 2141,2142, 2143, 2144, 2155, 2156

**We recommend Installation of this product by a Professional Plumbing Contractor**

**Note:** Regarding fittings, the use of petroleum based plumber's putty on our products will nullify the warranty. We recommend the use of clear silicone sealing materials as outlined by the manufacturer.

**To avoid damage to trim, all mating surfaces,(tile, paint, etc.), should be finished prior to trim installation. Recommended trim for installation 2050 or 2070, sold separately.**

**Shower Head Installation:**

As noted above, installer must use the appropriate 1/2" NPT SHOWER ARM (1), not included, for product installation.

1. Apply thread sealant to inlet end of SHOWER ARM (1a) and thread into FITTING (2) behind finished wall.
2. Apply a small bead of clear silicone to backside of FLANGE (4), not included, and slide over NIPPLE (1) and flush against wall.
3. Apply thread sealant to outlet end of SHOWER ARM (1b) and attach shower HEAD (3).

