

QUENTIN™  
DECK-MOUNT BATH FILLER

7440.900  
7440.901




Certified to comply with ANSI A112.18.1M

Thank you for selecting American-Standard...  
the benchmark of fine quality for over 100 years.


To ensure that your installation proceeds smoothly--  
please read these instructions carefully before you begin.

M965237 REV. 1.4 (5/17)

Recommended Tools



ROUGHING-IN DIMENSIONS




1 SPOUT ASSEMBLY

CAUTION

Turn off hot and cold water supplies before beginning.


- Install RUBBER RING (1) into ESCUTCHEON BASE (2).
- Insert SPOUT SHANK (3) through center hole of MOUNTING LEDGE. Make sure that the RUBBER RING (1) is properly seated in RECESS of ESCUTCHEON RING (2).
- Assemble RUBBER WASHER (4), BRASS WASHER (5) and LOCKNUT (6) onto SHANK (3). From underside of ledge tighten LOCKNUT (6) to secure SPOUT (7).



2

PREPARE TUBE AND TEE ASSEMBLY

- Prepare TUBE and TEE ASSEMBLY (1) to fit center to center VALVE (2) location (between 6-1/2" and 12"). If necessary, cut and/or bend TUBING carefully. Make sure tube bend is close to the TEE (1) so that it will not effect the compression joint at the VALVE CONNECTION.
- Remove COUPLING NUT (3) and FERRULE (4) from each VALVE (2) and slide onto TUBING (5).





NOTE

VALVE inlet is 3/4-inch NPT male.


### 3 VALVE ASSEMBLY

- Install LOCKNUTS (1) and RUBBER WASHERS (2) onto valve shanks.
- Push TUBING (3) ends into VALVE (4) side outlets. Insert VALVES (4) into mounting holes from underside of ledge.
- Press TEE (5) onto SPOUT SHANK (6) making certain that the O-RING (7) is properly seated on SHANK (6). Push COUPLING (8) into TEE (5) and attach to SPOUT SHANK (6) and tighten using a 10mm (3/8") hex wrench. Tighten COUPLING (8) using a 10mm (3/8") Hex wrench. (FOR 7440 .901). Use COUPLING (8a) for fitting less spray.
- Thread of VALVE BODY (4) should extend at least 5/16" inch above MOUNTING SURFACE (11). If necessary, adjust LOCKNUT (1).
- Place RUBBER RING (10) into ESCUTCHEON ADAPTERS (9) and thread onto valves until snug against internal stop.
- Tighten LOCKNUT (1) with WRENCH supplied to secure VALVE (4) position.
- Slide FERRULE (12) and COUPLING NUT (13) to outlet of VALVE (4) and tighten COUPLING NUT (13) firmly.
- Connect HOT water supply to inlet of left VALVE and COLD water supply to inlet of right VALVE using appropriate connector.




### 4 INSTALL HANDLES

- Push ADAPTER (1) on VALVE STEM (2). See Fig. A. Tighten STEM SCREW (3) to secure ADAPTER (1).
- Find correct position of LEVER HANDLE ASSEMBLY (4) by adjusting male teeth on ADAPTER (1) to female teeth in HANDLE (4).
- Thread LEVER HANDLE ASSEMBLY (4) onto DECK ADAPTER (5) until snug against mounting surface.



### 5 SERVICE


- To change direction of handle rotation, proceed as follows:
  - Turn valve to OFF position.
  - Thread counter-clock wise HANDLE BASE (1) to remove HANDLE ASSEMBLY (2) from ESCUTCHEON BASE (3).
  - Use a flat blade screw driver to remove SPRING CLIP (4).
  - Lift STOP WASHER (5), turn 90° and replace.
  - Replace SPRING CLIP (4).
  - Reinstall HANDLE ASSEMBLY (2).
- If spout drips, operate handles several times from OFF to ON position. Do not force - handles turn only 90°.



## 6 HANDSHOWER INSTALLATION (For 7440.901 only)


- Drop SPRAY ESCUTCHEON (1) through the fourth hole of the tub ledge (12" max from SPOUT center) with SPRAY ESCUTCHEON (1) directed towards tub center. Be sure RUBBER RING (2) is properly seated in SPRAY ESCUTCHEON (1). Install RUBBER WASHER (3), BRASS WASHER (4) and LOCKNUT (5) from underside of ledge.
- Secure SPRAY ESCUTCHEON (1) by tightening LOCKNUT (5).
- Install SEAL (9) and connect HOSE (10) to outlet nipple at the bottom of TEE (7). Tighten firmly.
- Slip SHOWER HOSE (8) with COUPLING NUT through SPRAY HOLDER (6) and SPRAY ESCUTCHEON (1). *Note: SPRAY HOLDER (6) must be separate from ESCUTCHEON (1) to pass HOSE (8) through ESCUTCHEON (1)*
- Insert SEAL (9) into SHOWER HOSE (8). Connect HOSE (8) to HOSE (10).
- Install SEAL (9) and connect HAND SHOWER (11) to SPRAY HOSE (8).

**NOTE** When not in use, HANDSHOWER should be seated in the HOLDER.



## 7 MAKE WATER SUPPLY CONNECTIONS

- Connect HOT water supply to LEFT INLET UNION (1) and COLD water supply to RIGHT INLET UNION (2). Pipe connections are 3/4" NPT. Use sealant or Teflon tape on pipe connections. *Do not solder directly to valve body.*




## 7A TEST INSTALLED FAUCET

- With HANDLES in OFF position, turn on WATER SUPPLIES and check all connections for leaks. ➡
- Operate both HANDLES to flush water lines thoroughly.
- Lift HAND SHOWER from HOLDER, direct spray into tub. Lift TRANSFER KNOB to check HAND SHOWER and HOSES for leaks. ➡
- Turn handles "off" and replace HAND SHOWER.

## 8 Before the bathroom is completely finished, you may want to remove spout, handshower, and handles to avoid damage during construction.

- To remove handles, reverse steps in section 4.
- To remove SPOUT (1), proceed as follows:
  - Unthread LIFT ROD KNOB (2) and remove.
  - Remove SET SCREW (3) using 4mm hex wrench supplied.
  - Lift SPOUT (1) off SHANK (4) carefully and remove RUBBER RING (5).
  - Unthread SHANK SLEEVE (6) and remove from SHANK (4).
  - Reverse sequence to re-install SPOUT (1). Be sure RUBBER RING (5) is properly seated in its recess at the base of the SPOUT (1). Make certain SET SCREW (3) is properly aligned and tight so that SPOUT (1) is locked in place.



## 9 CARE INSTRUCTIONS:

**DO: SIMPLY RINSE THE PRODUCT CLEAN WITH CLEAR WATER. DRY WITH A SOFT COTTON FLANNEL CLOTH.**  
**DO NOT: DO NOT CLEAN THE PRODUCT WITH SOAPS, ACID, POLISH, ABRASIVES, HARSH CLEANERS, OR A CLOTH WITH A COARSE SURFACE.**

*American Standard*

**QUENTIN™**

**DECK-MOUNT  
BATH FILLER**

MODEL NUMBER

**7440.900**  
**7440.901**

**M964290-YYY0A**  
SPOUT KIT (7440.901)

**M964291-YYY0A**  
SPOUT KIT (7440.900)


**M970057-0070A**  
SET SCREW

**A922388-YYY0A**  
STREAM STRAIGHTNER

**M964159-YYY0A**  
HANDLE  
ASSEMBLY




**M962902-YYY0A**  
TRANSFER  
ROD ASSEMBLY



Replace the "YYY" with  
appropriate finish code

CHROME	002
OIL RUBBED BRONZE	224
SATIN NICKEL	295

**M962619-0070A**  
DECK  
ESCUTCHEON KIT




**918555-0070A**  
HANDLE SCREW




**918049-0070A**  
HANDLE ADAPTER




**994053-0070A**  
VALVE



**M961634-0070A**  
VALVE  
MOUNTING  
KIT




**012078-0070A**  
VALVE COUPLING KIT




**030275-0070A**  
SHANK SLEEVE KIT




**030274-0070A**  
SHANK MOUNTING KIT



**012668-0070A**  
SHANK KIT



**028679-0070A**  
TUBE & TEE  
ASSEMBLY




**028699-0070A**  
COUPLING (FOR TRANSFER)



**028698-0070A**  
COUPLING




**A952849-0070A**  
CHECK VALVE




**1660141-YYY**  
HAND SHOWER




**028664-YYY0A**  
HAND SHOWER  
HOLDER



**028667-0020A**  
HAND SHOWER HOSE



**051343-0070A**  
HOSE KIT



**HOT LINE FOR HELP**

For toll-free information and answers to your questions, call:  
1 (800) 442-1902  
Mon. - Fri. 8:00 a.m. to 8:00 p.m. EST  
Saturday 10:00 a.m. to 4:00 p.m. EST  
IN CANADA 1-800-387-0369  
(TORONTO 1-905-306-1093)  
Weekdays 8:00 a.m. to 7:00 p.m. EST  
IN MEXICO 01-800-839-1200



PART OF **LIXIL**