

INSTALLATION INSTRUCTIONS:

- Be sure wax ring is at least 70°F in temperature to insure proper flow of wax.
- 2. Place bolts in floor flange, secure with retainer washer.
- 3. Press wax ring over horn outlet of the toilet bowl.
- 4. Set bowl in place and use body weight to compress wax. Twist bowl slightly to spread wax.
- 5. Place washers and nuts on bolt. Tighten bolts carefully to prevent breaking bowl.