



INSTALLATION INSTRUCTIONS:

- 1. Be sure wax ring is at least 70°F in temperature to insure proper flow of wax.**
- 2. Place reinforced wax ring firmly onto urinal flange.**
- 3. Set urinal firmly against flange and use body weight to compress wax. Twist urinal slightly to spread wax.**
- 4. Tighten bolts (not included) carefully to prevent breaking the urinal.**