

INSTALLATION INSTRUCTIONS

1. Connect bottom outlet to spout using a new piece of 1/2" (12.7mm) threaded pipe installed so that end projects out from wall surface 5/8" (15.87mm) to 1-5/8" (41.2mm).
 2. Apply PTFE tape to pipe threads and hand tighten adapter onto threaded pipe. Finish tightening with adjustable wrench one additional turn.
 3. Hand tighten tub spout onto adapter taking care not to damage the o-ring.
- Important:** Tighten spout a minimum of one additional turn or until all slack is taken up behind wall.
-

INSTRUCCIONES DE INSTALACIÓN

1. Conecte la salida inferior al surtidor utilizando una pieza nueva de tubo roscado de 1/2" (12.7mm) de modo que el extremo sobresalga de la superficie de la pared de 5/8" (15.87mm) a 1-5/8" (41.2mm).
 2. Aplique cinta PTFE a la rosca del tubo y apriete el adaptador a el tubo roscado manualmente. Termine de apretar con una llave ajustable dando una vuelta adicional.
 3. Apriete manualmente el surtidor al adaptador cuidando de no dañar la junta tórica.
- Importante:** Apriete el surtidor dando una vuelta adicional como mínimo o hasta que ajuste.

