
## **ASSEMBLY INSTRUCTIONS**









## **Cristol Tiered Pendant**

Item # ARN 5401

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING\*\*\*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.


INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- 1. Carefully remove all parts from the box.
- 2. A 1/4" threaded nipple must be installed in your outlet box. Then install the threaded nipple (B) into the outlet box.
- 3. Let the crystal ball (G) pass through the tube (H) & (F).
- 4. Twist the power supply and ground wire together and push through the tube (H & F).
- 5. Thread the tube (H) to the connector (I), and tube (F) to the tube (H).
- 6. Let canopy (D) and lock collar (E) go through the tube,let wires go through the ceiling loop (C), then install the fixture body to the ceiling loop (C).
- Measure the wires then cut. Be certain to leave enough to connect inside of the outlet hox
- 8. Strip the insulation back on the two power supply wires about 5/8".
- Connect the fixture Ground (bare) wire with the ground wire from the outlet box using
  wire nut (A). If your house does not have ground wire, then attach this wire to the
  green grounding screw inside of the outlet box.
  - IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.
- 10. Connect the fixture Neutral (ribbed, no markings) wire with the neutral wire from the outlet box using wire nut (A).
- 11. Connect the fixture Hot (smooth edge,markings) wire with the hot wire from the outlet box using wire nut (A).
  - DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

## **ASSEMBLY INSTRUCTIONS**









## **Cristol Tiered Pendant**

Item # ARN 5401

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING\*\*\*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

- 12. Tuck these wire connections neatly into the outlet box to secure.
- 13. Put canopy (D) to ceiling loop (C), and secure with lock collar (E).
- 14. Insert bulbs (not included) into the sockets.
- 15. Thread the glass shade (K) to the metal cap (J).
- 16. Installation is complete, turn on power at fuse or circuit breaker.

<sup>\*\*\*</sup>Clean with a dry,soft cloth only. Use no harsh abrasives or chemical agents.