

## LAVATORY DRAIN INSTALLATION INSTRUCTIONS

MODEL No: 330, 3301, 3302, 3303

### Recommended Installation by a Professional Plumbing Contractor

**Note:** The use of petroleum base plumbers putty on product will nullify warranty. We recommend the use of clear silicone sealing material.

### Installation instructions:

1. Remove FLANGE, WHITE WASHER, and discard drain CAP from drain assembly. Place WHITE WASHER into FLANGE. Then, place FLANGE through the sink hole (Clear silicone may be used in place of WHITE WASHER).
2. From underside of sink install CONE WASHER, STEEL WASHER, and thread LOCK NUT firmly.
3. Thread TAILPIPE to FLANGE assembly.
4. Tailpipe to be received by existing P-Trap.

