



1/8"











Plus:
• 1-1/4" copper tube or 1/2" nipple
• Emery paper

Plumbers Putty	Sealant Tape	Silicone Sealant	•

Record your model number below for future reference:	Important Information Observe all local plumbing and building codes.	1 Install the escutcheon on the spout.	2 Slip-Fit Spout: Install the tube 1-9/16" (40 mm) from the wall.	Use emery paper to remove burrs.
			X	
Apply plumbers putty or sealant to the escutcheon, leaving a gap at the bottom.	Loosen the setscrew. Slide the spout and escutcheon against the wall. Tighten the setscrew.	3 Threaded Spout: Apply sealant tape to a 1/2" nipple.	Install the nipple 1-3/4" (44 mm) from the wall.	Loosen the setscrew to remove the slip-fit assembly.
	1/8"		X	1/8"
Apply plumbers putty or sealant to the escutcheon, leaving a gap at the bottom.	Use a clean strap wrench to install the spout.	4 Wipe away excess sealant.	·	
1284109-2- ∆				

