



WALL-MOUNT POT FILLER

INSTALLATION INSTRUCTIONS

Before installing, read entire installation instructions. Observe all local building and safety codes.

For the following installation instructions it is assumed that a cold water supply line has been installed in the desired pot filler location behind the finished wall.

A ½" lug ell installed to wood blocking behind the finished wall should be attached to the water supply line with a ½" pipe nipple extending ½" from the wall.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-866-855-2284. If you need assistance or have questions while installing your Pot Filler, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing kitchen fixtures. Signature Hardware accepts no liability for any damage to the floor, walls, plumbing or for personal injury during installation.

TOOLS AND MATERIALS:

Thread Sealant or Plumber's Tape
Allen Wrench (provided)

Silicone Sealant

Damp Cloth

INSTALLATION

1. Place thread sealant or plumber's tape on the ½" pipe nipple.
2. Run a bead of silicone sealant along the base of the pot filler.
3. Thread your pot filler onto the ½" pipe nipple.
4. Make sure the base of the pot filler is firmly against the wall, and wipe away any excess sealant with a damp cloth.
5. Attach the pot filler handles and secure with the Allen wrench (provided).