

MARINOS

SINGLE-HOLE BIDET FAUCET

SKU: 935804

BEFORE YOU BEGIN

We recommend consulting a professional if you are unfamiliar with installing plumbing fixtures. Signature Hardware accepts no liability for any damage to the faucet, plumbing, bidet, or for personal injury during installation.

Observe all local plumbing and building codes.

Unpack and inspect the faucet for shipping damage. If any damage is found, contact our Customer Relations team at 1-866-855-2284.

GETTING STARTED

- Ensure that you have gathered all the required materials that are needed for the installation.

TOOLS AND MATERIALS:



Adjustable
Wrench



Silicone Sealant
(100% Neutral Cure)



Damp Cloth

For Warranty information, please visit: signaturehardware.com/services/warranty

REVISED 05/20/2020
CODES: FH-8568-D76-U

INSTALLATION

1. If a lock nut is included and attached to the faucet body, unthread to remove. If there is no lock nut or it is separate from the faucet, move on to the next step.

2. Attach the flexible water feed tubes to the tail-piece. Hot water is always on the left and cold water is always on the right. If the water feed tubes are already connected, move on to the next step.

3. If included, place the metal mounting washer, or clip, and rubber sealing gasket over the mounting hole. If there is no top mounting washer or gasket, move on to the next step.

4. If a decorative mounting plate, or escutcheon, is included, place it over the mounting hole. If there is no decorative plate, move on to the next step.

5. If your faucet includes a separate mounting rod, remove the mounting nut and screw the rod into the faucet body. Thread the rod, and water feed tubes through the mounting hole. Thread the mounting nut onto the rod from underneath the sink. Make sure that faucet is properly aligned, and tighten the nut with your adjustable wrench.

If your faucet does not include a mounting rod, thread the faucet tail-piece and water feed tubes through the mounting hole and mounting hardware. Thread the washer (if included) and lock nut onto the tail-piece from underneath the sink. Make sure that faucet is properly aligned, and tighten the nut with your adjustable wrench.

6. Hand tighten to attach the water feed tubes to the main water supply, being careful not to cross the two during installation. Give a ¼ turn with pliers or wrench, but do not over tighten. Curve tubes as necessary to ensure there are no kinks or knots.

Note: If needed, you can connect 1/2" water feed tubes to a 3/8" water supply with faucet connectors available at your local hardware store. If there is a nut at the end of the water feed tubes, connect with a 1/2" pipe nipple.

7. To install the new pop-up drain, apply a bead of silicone sealant to the underside of the drain flange and place it in the mounting hole. If there is no pop-up drain, move on to step 11.

8. Thread the lock nut onto the drain pipe and tighten with your adjustable wrench.

9. Wipe away any excess sealant around the drain using your damp cloth.

10. Attach the P trap to the drain pipe and wall drain fitting, and tighten the lock nuts.

11. When your faucet installation is complete, turn on the water supply. Check to make sure that all connections are tight (no water should be leaking) and that the hot and cold supplies are working correctly. Turn the water on and allow the water to flow through the spout for approximately 60 seconds.