



ULTRA ROMAN TUB FAUCET

Before installing, read entire installation instructions. Observe all local building and safety codes.

For the following installation instructions for your new faucet is assumed that any old fixtures have been removed and any repairs or modifications to the water supply have been completed.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1-855-715-1800. If you need assistance or have questions while installing your faucet, contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing bathroom fixtures. Signature Hardware accepts no liability for any damage to the floor, walls, plumbing or for personal injury during installation.

TOOLS AND MATERIALS:

Adjustable Wrench

Basin Wrench

Allen Wrench (provided)

INSTALLATION

1. Disassemble the spout, handle, diverter, and hand shower holder bodies and reassemble to attach to the mounting surface.

Note: Remove any set screws with the provided Allen wrench. When all pieces are in the proper position, tighten the set screws to secure.
2. Attach the flexible water feed tubes according to the installation drawing (page 2). Curve tubes as necessary to ensure there are no kinks or knots.
3. Attach the hand shower hose to the water feed tube and hand shower.
4. Connect the main water supply lines to the hot and cold handles.
5. After all connections have been made, turn on the water supply, check to make sure that all connections are tight (no water should be leaking) and that the hot and cold supplies are working correctly. Turn the faucet on and allow the water to flow through the spout for approximately 60 seconds. Divert the water to the hand shower and allow the water to flow through the hose for an additional 60 seconds.

