

INSTRUCTIONS FOR PVC SHOWER DRAIN WITH TEST PLUG

1. Assure that the spud and strainer combination is threaded down to a point where solid contact is made with the orange test plug. Perform required tests.

Note: Plug should be flush with drain opening. See Photo A.

2. Remove spud and strainer combination. Use pliers to dislodge the orange test plug from the drain, and discard in an approved receptacle.



Photo A
Foto A

INSTRUCCIONES PARA EL DESAGÜE DE DUCHA DE PVC CON TAPÓN DE PRUEBA

1. Asegúrese de que la combinación de espiga y colador esté enroscada hasta un punto donde se haga un contacto efectivo con el tapón de prueba naranja. Efectúe las pruebas requeridas.

Nota: El tapón debe estar a ras con la abertura del desagüe. Consulte la foto A.

2. Retire la combinación de espiga y colador, utilice unos alicates para desprender el tapón de prueba naranja del desagüe y deséchelo en un recipiente aprobado.