## **INSTRUCTION GUIDE** ROOF FLASHINGS



1	Make sure the roof is free of all debris and is ready for shingle installation.
2	Chamfer the pipe end prior to the flashing installation.
3	Install the shingles in rows starting from the bottom of the roof and work upwards to the peak. (Be sure to overlap the row below for good waterproofing qualities.)
4	Once you are near the pipe penetration, push the flashing down over the chamfered pipe end and position it flush against the felt paper layer and shingles.
5	Secure the flashing with roofing nails and make sure that all nails are concealed under the next few rows of shingles to keep the roofing system leak free.
6	Install the shingles in rows to the top of the roof.
7	Test the flashing by running water over it for 3 to 5 minutes.

©2020 Oatey SCS. All Rights Reserved. This information is based on data believed to be reliable but Oatey makes no warranties, express or implied, as to its accuracy and assumes no liability arising out of its use. The data listed falls within the normal range of product properties but should not be used to establish specification limits or used alone as the basis of design. Oatey's liability to purchasers is expressly limited to the terms and conditions of sale. Oatey is trademark of Oatey Co. All other trademarks can be found www.Oatey.com.