

INSTRUCTION GUIDE

THREAD SEALANT



1 Clean the threads of the pipe and fitting to remove oil, dirt and debris.

2 Stir the compound using its applicator brush.

3 Brush the compound on the male threads of the pipe, turning to coat all sides. Avoid brushing any compound into the pipe.

4 Your pipe is ready to be threaded into the fitting. Excess compound remaining after the pipe has been threaded into the fitting should be wiped off.

