

INSTALLATION INSTRUCTIONS SLIDE BAR  
ASSEMBLY  
MODEL NO. 294, 294-I, 295, 295-I, AND 280T

NEWPORT BRASS®

Flawless Beauty. From Faucet to Finish.™

**Recommended Installation by a Professional Plumbing Contractor**

Locate the desired position of slide bar on finished wall. **See Fig. 1.**

Mark wall and drill 5/16" hole for WALL ANCHORS (2) using WALL BRACKET (1) for hole pattern template.

Note: Due to vibration in shipment, tightening of SETSCREW (7), shown in **Figure 2**, may be required before proceeding to next step.

- Place ESCUTCHEON/O-RING (6) onto SLIDE BAR assembly (4) and push forward to expose the base of end post as shown in Figure 3.
- Place SLIDE BAR assembly (4) onto mounted WALL BRACKETS (1) fixed by SCREW (3) and secure into place with SETSCREWS (5), three on each end, as shown in **Figure 3**.
- Slide ESCUTCHEON/O-RING (6) back over end post and flush with finished wall.

