## 6" & 8" Back To Back Door Pull Mounting Instructions \*Refer to the template on this page for hole locations (A and B). \*Drill holes in door 5/16" (8.0mm) not to exceed 3/8" (9.5mm) diameter at 6" or 8" on center. \*Door Thickness 1 3/8" (35.0mm) ~ 1 3/4" (44.0mm). 5/16"(8.0mm) One One: Unscrew spindle from threaded shank keeping threaded shank fully inserted into door pull and tighten. Pass threaded shanks through predrilled holes in door. Two Two: Take spindle and perpare to screw onto threaded shank from other side of door. Three 6.0" Three: Screw spindle onto threaded shank until it stops Four and tighten. 8.0" Four: Insert second pull over both the spindles. Five Five: Tighten both set screws. Door 5/16"(8.0mm) GDMTG1 GDMTG2 Suit For: G420-6 Suit For: G420-8 G715-6 G715-8 G718-6 G718-8 G855-6 G855-8 5/16"(8.0mm)