

# PROTECTIVE CARPET FILM

## TECHNICAL INFORMATION SHEET

Available in eight roll sizes:

**24"X50' / 100**<sub>sq ft</sub>

**24"X100' / 200**<sub>sq ft</sub>

**24"X200' / 400**<sub>sq ft</sub>

**30"X200' / 500**<sub>sq ft (3 mil)</sub>

**36"X200' / 600**<sub>sq ft</sub>

**36"X500' / 1,500**<sub>sq ft</sub>

**48"X500' / 2,000**<sub>sq ft</sub>

**36"X1,000' / 3,000**<sub>sq ft</sub>

Reverse wound for easy application, this adhesive Carpet Film protects against spills, dirt and foot traffic. Once applied, it provides a tight bond with soft surfaces such as carpet, yet it's easy to remove and leaves no residue.

### PROTECTS FROM:

**PAINT / DIRT / HEAVY TRAFFIC + OTHER SPILLS**

### ADVANTAGES:

**SELF ADHERES QUICKLY AND SMOOTHLY**

**EASY-TO-USE & REMOVE**

**2 MIL. NON-SKID SURFACE**

**STAYS ON STAIRS**

**REVERSE WOUND FOR EASY APPLICATION**

**PROTECTS AGAINST SPILLS, DIRT & FOOT TRAFFIC**

**HIGHLY TEAR RESISTANT**

**NO RESIDUE OR DAMAGE TO SURFACE**

**UP TO 45 DAYS ON SYNTHETIC FIBER CARPET\***

*\*Never apply to hardwood floors, wool carpet, ceramic tile or laminate flooring. Do not apply to wet or damp carpets. Allow 72 hours before applying to newly laid carpets.*

### PRODUCT SPECIFICATIONS:

Thickness	mil	2
Film	type	LDPE+LLDPE
Adhesive	type	Modified Acrylic PSA
Elongation	%	500 to 700
Tensile Strength	lb/inch	4 to 6
Adhesion	ounce/inch	17 to 23
Unwind Force	ounce/inch	5 to 7

#### TESTING STANDARDS

Thickness - ASTM D6988

Elongation and Tensile strength - ASTM D882

Adhesion - ASTM D3330

Unwind Force - ASTM D3811

### BEST PRACTICES:

TEST OVERNIGHT BEFORE APPLYING TO THE ENTIRE SITE.

*The purchaser &/or user assumes all risk & liability in connection with this product.*

*Never apply to hardwood floors, wool carpet, ceramic tile or laminate flooring. Do not apply to wet or damp carpets. Allow 72 hours before applying to newly laid carpets.*

### INSTALLATION:

1. Peel back the edge of the protective film & unroll it slightly. Press the edge down at the beginning of the area to be covered so that it adheres firmly to the surface.
2. Apply pressure & smooth down as you go. When you reach the desired length carefully cut.

TIP: Fold the edge of the film back against the roll for easy re-use.

**IN CASE OF SPILLS:** Carpet Film will keep liquid from seeping through, but to prevent tracking onto clean surfaces it's best to wipe spills.