

Assembly Instructions: Mop Bucket Casters

PRODUCT NUMBER: 36904, 36908, 36918

Included:
4 Casters
4 Spacers

Steps:

1. Insert spacers into each hole on the bottom of the bucket.

2. Using a rubber mallet, tap each spacer so it fits securely against the bucket.

3. After the spacers are installed, insert each caster into the spacer by hand until secure.

4. Complete installation by using a rubber mallet to tap each caster into place.

