


SPARE SPRINKLER HEAD STORAGE CABINET

Figure 1019



DIMENSION (INCHES)

PART NUMBER	SIZE	LENGTH	DEPTH	HEIGHT
NFP101903	3 Head	7.36	2.41	5.02
NFP101906	6 Head	14.21	2.41	5.02
NFP101906E	6 Head - ESFR	14.21	3.18	6.18
NFP101912	12 Head	14.21	4.00	5.02

INSTALLATION

Install using the appropriate fasteners for the application. Insert fastener from inside the box into each pre-punched hole located on the back of the spare head box and securely fasten to the wall.

FEATURES & BENEFITS

- Allows for on-site storage of spare heads and head wrenches per NFPA guidelines
- Includes knockouts to accommodate common sprinkler sizes
- Hinged door to protect contents from the elements
- Mounting holes for easy installation on most surfaces

SPECIFICATIONS

- Material: Steel
- Finish: Red
- Available sizes:
 - 3 head cabinet
 - 6 head cabinet
 - 6 ESFR head cabinet
 - 12 head cabinet